
LockState RL 4000 User Guide



Table of Contents

Section 1: General Overview

1. Foreword	3
2. Important Information	3
3. Software Installation	4

Section 2: Initial Lock Setup – Manual Management

1. Adding Lock to Code Generation Software	6
2. Setting Up Your Lock	7

Section 3: Initial Lock & User Setup – Software Management

1. Lock Setup	8
2. User Setup – Issuing Permanent Codes & iButtons	11
3. Remote User Code Generation	14

Section 3: Advanced Access Control Management

1. Time Shift Setting	18
2. Time Lock Operation Setting	19
3. Activation/Expiration Setting	21
4. Audit Trail	22
5. Exception Date Setting	23
6. Mission Management	24
7. Copy Lock Setting	26
8. History	26

Section 1: General Overview

1. Foreword

About This Manual

This manual is designed for users of ResortLock software. All installation, setup, operational information, procedures, screen captures, and other relevant materials are contained in this manual.

Safety Warnings and Cautions

When handling a print circuit board (PCB), to guard against possible static discharges, touch a grounded object BEFORE touching the board. Static shock could cost unexpected damage of the board.

Design Change Disclaimer

Due to design changes and product improvements, information in this manual is subject to change without notice. LockState assumes no responsibility for any errors that may appear in this manual.

Reproduction Disclaimer

Neither this manual nor any part of it may be reproduced, photocopied, or electronically transmitted in any way without the written permission of LockState.

Technical Support

When you experience any difficulty installing or operating the ResortLock software, please contact LockState at 1-888-924-5625.

2. Important information

Manufacture Default Code Setting:

1. Default Setting for Login User Name / Password is: dallas / ibutton
2. Operator Password: The default operator password is 00000000 (8 digit Zeros)
3. System Password (Facility Code): The default System password is 000000 (6 digit Zeros)

LED and Audio Indicator:

1. Program Mode: LED indicating GREEN, audio end with two beeps (Successful)
2. Program Mode: LED indicating Red, audio end with one beep (Fail)
3. Key Access Mode: LED indicating GREEN, audio end with two beeps (Valid Access)
4. Key Access Mode: LED indicating Red, audio end with one beep (Fail)
5. Unlock Mode: LED flashing GREEN, lock is in unlock mode
6. Lock Mode: LED flashing RED, lock is in lock mode

Important Keys:

1. DS1982/DS1990- User Key (Default key-fob color from UCA: red, yellow, black, orange)
2. DS1994/DS1904- It contains an on board real time clock to reset the lock internal clock. (Default key-fob color: Green)
3. DS1977- Program Key. (Default key-fob color: Purple)
4. DS1996- Firmware Upgrade Key (Default key-fob color: Blue)

3. Software Installation

To Download Software, go to <http://resortlocks.com/E4-iKPAD.ZIP>

- Once downloaded, unzip and select “SETUP” file. Follow instructions to install.
- After installed, open “Eternity4-ikpad” icon on your desktop.

Operating System

ResortLock software is comparable with Microsoft Windows 98/2000/XP/Vista. All software must be installed using Windows administrator account, but all levels of Windows users can use the program. Failure to install the applications may result in error messages and an incomplete installation.

Step 1: Install 1-Wire USB Driver First

This driver will allow use of the iWire (the connector for the iButton)


1. Download driver from <http://resortlock.com/Downloads/1-wire.zip>
2. Select *1-Wire USB Driver Installation*, the Setup Wizard will guide you through the steps.
3. Select *Next*. The *License Agreement* screen displays.
4. Select *I Agree*, then *Next*. *1-Wire USB Driver Warning* screen displays.
5. Select *Next*. The *Select Installation Folder* screen displays. Check everyone or just me.
6. Select *Next*. The *Confirm Installation* screen displays, then select *Next* to start installation.
7. Select *Finish*. The 1-Wire USB Driver Installation is complete.
8. Plug the 1-Wire into the USB adapter and then the USB adapter into your computer.

Step 2: Install the ResortLock Software

1. Download software from <http://resortlock.com/Downloads/RL4000-Software.zip>.
2. Once downloaded, unzip the zip file (right click on zip folder, select “Extract All”). Then follow instructions for extracting.
3. Open unzipped folder and double click on SETUP.EXE file.
4. The Auto installer will guide you through the steps and create the shortcut –“ikeypadlock Management” on your desktop.

Step 3: Running ResortLock Software

1. Make sure you have plugged in the iWire to the USB adaptor and the USB adaptor into your computer before starting the software.
2. Double Click on “Eternity4-ikpad” icon on your desktop.
3. Login – User Name: **dallas**, Password: **ibutton**



Default User Name and Password can be modified but can't be deleted.

4. Change System Password

The default system password is 000000(6 Zeros). It is mandatory to change and remember the facility system password when the user is ready to use this software. It is highly recommended that the system password need to be changed from the default setting for security purpose.




Section 2: Initial Lock Setup – Skip if you have Software Management Package (with iWire)

Step 1 Adding Lock to Code Generation Software


1. Lock Setting

Before you can generate remote codes, you will need to add your lock to the software. Select “Lock Setting” by clicking on the Lock Setting Icon. You can get to the Lock Setting screen either by clicking the lock icon in the upper menu or the side menu.



2. Add New Lock

- a. First, click on the “Add” button to input information from your lock.



The screenshot shows the 'Eternity4 ikpad (V2008.08.16) - [Lock Setting]' window. The 'Mission Management' menu is open, and the 'Add' button is highlighted with a red arrow. The 'Lock Information' section contains the following fields:

- Serial ID: [Empty]
- Lock Name: [Empty]
- Lock Status: No Limit Cl... (dropdown)
- Lock Location: [Empty]
- Lock Type: [Empty]

The 'Assigned Key List' section shows a table with the following columns: First Name, Last Name, User Type, Serial ID, Key Code, Status, Department, Title, Address. The table is currently empty.

- b. Next, enter the information for your lock:
- Enter the 16-digit serial number shown on the back of your lock.
 - For Lock Status, keep it as the default option.
 - For Lock Type, select “Access Code”.
 - Enter a lock name, such as “Vacation Rental”.
 - For Lock Location, enter the address where the lock is located.
- c. Hit the “Save” Button to save your lock information.



The screenshot shows the 'Eternity4 ikpad (V2008.08.16) - [Lock Setting]' window. The 'Save' button is highlighted with a red arrow. The 'Lock Information' section contains the following fields:

- Serial ID: A7090000B4FBE01
- Lock Name: RLDemo Lock
- Lock Status: No Limit Storehouse M
- Lock Location: 1325 South Colorado Blvd, Denver
- Lock Type: Access Code

The 'Assigned Key List' section shows a table with the following columns: Serial ID, Lock Name, Lock Location. The table contains one row:

Serial ID	Lock Name	Lock Location
A7090000B4FBE01	RLDemo Lock	1325 South Colorado Blvd, Denver, CO 80222

- d. The information should now display in the field below. Lock Setting is now complete.

Step 2: Setting Up Your Lock

1. Master Code

Before you can issue new permanent codes on your lock or set the time on your lock, you'll need to set your master code on the lock. **Your lock will not work unless you set up a new master code.** The master code will allow you to program your lock. It will not be used to unlock your door. Again, it is just for programming purposes. Your master code can be anywhere from 1-6 digits. The default code master code is **123456**. If you ever have to reset your lock, it will go back to the default master code.

Your New Master Code: _____ (3-6 digits)

To set your new master code to the lock, enter the following into the lock:

123456 # 11 # Your Master Code # Your Master Code Again

* Press each button slowly, not too fast. After every time you press # you will hear 2 quick beeps and see 2 quick green flashes and then a flashing red light.

* If done **incorrectly**, you'll hear a long beep and see a solid red light and will need to start this step over.

* If done **correctly**, after the last # you press you'll hear 2 quick beeps and see 2 quick green flashes and then the keypad light will go out.

* You have now set your new 3-6 digit master code. You are allowed to have multiple numbers like 33433 as your code. Make sure you wrote it down.

* If you lose or forget your master code you will have to reset the lock and start over. To do this, press the reset button on the back of your lock with a pin or small screw driver. The reset button is located just below the battery compartment.

2. Setting the Time & Date

This sets the time zone that the lock will be located in so that the codes you issue will be in sync with the lock.

- Enter the following into the lock to set the time zone. Please note that the time is code is in military or 24 hour time format.

Master Code # 88 # YYMMDDHHMM

Example: If the date and time is 05/30/2008 at 3:32PM, you would enter:

Master Code # 88 # 0805301532

* If done correctly you'll hear 2 quick beeps and see 2 quick green flashes and then the keypad light will go out. If done incorrectly you'll hear a long beep, see the red light, and will need to start this step over again.

3. Other Functions


- For other functionality like setting permanent codes, adding iButtons, auto lock/unlock and more, please see [Appendix A: Quick Operation Guide](#) for more info.

Section 3: Initial Lock & User Setup – Software Users


1. Lock Setup

First you'll need to add your lock's information, such as the serial number, name & address, to the software. This will synchronize the software to the lock and is necessary before remote access codes can be generated. To do this, we'll be using the iButton. This information will be taken from the lock by touching the iButton programming key to the lock. But before we can do that, we first need to send the lock on a "mission" to get that information. Here is how to do that...

Step 1: Select New Lock Setup Mission from the menu.



➤ The following screen will then appear.



Step 2: Connect the iButton

Snap the iButton program key (purple key) into the iWire blue dot receptor. Use good force until the iButton snaps into place.

Step 3: Issue Key


- Select Daylight Saving if it is daylight savings time.
- Select Classroom mode to leave the lock open after it is unlocked.
- Select Storehouse mode if you want the lock to remain open after it is unlocked. (User can always lock the door by hitting the “Lock” button on the inside of the door.

This mission will accomplish the following:

- ✓ Retrieve the lock’s serial number
- ✓ Initialize the lock back to the manufacture default setting.
- ✓ Sets the system password, and real time to the lock.
- ✓ Set Daylight Saving enable or disable
- ✓ Set Lock Mode to normal open or normal close
- ✓ Set LED Blinking or idle

Step 4: Retrieve Serial Number From Lock


1. Before touching the iButton to the lock receptor, reset the lock by pressing the reset button (small button just below batteries) with a pin or small screw driver for one second.



2. After depressing the button you will hear two beeps and see a solid green light on the front of the lock.
3. While the led is solid green, touch the program key to the iButton reader on the lock (two beeps). Now the lock information is retrieved from the lock.

Step 5: Import Lock Information Back into Software

1. Snap the program key back onto the USB blue dot receptor
2. Click the “Read Key” icon on the menu bar




3. The new **lock id** number will appear in the retrieve window. Now click the **Add Lock icon**. (If the lock already exists in the system, the “exist in database” will show “True”, and you can’t add the same lock to the system).
4. Type in a lock name, location, status, and lock type, then click the save button. You are now ready to use the lock management software. If you have more locks, you can add them by following the same steps.

2. User Setup – Issuing Permanent Codes and iButtons

This section will show you how to create new user codes and then program them into the lock. To set up new iButton and permanent code users, do the following:

Step 1 – Add Codes/iButtons to RL Management Software

1. Go to the **Setting Menu** and Select **Key Setting** Screen.



2. Add User Information:



To add/edit iButton /keycode user, click the  button in the upper menu, and following screen will pop up:

The dialog box titled "Select User Type" contains two radio buttons: "iButton User" (which is selected) and "Key Code User". Below the radio buttons are two buttons: "OK" with a green checkmark icon and "Cancel" with a red X icon.

Select either iButton User (to add iButton) or Key Code User (to add code) depending upon the type of access you want to provide.

To Add iButton User:

- Click ok and snap the user iButton key into the encoder (black iButton).
- Click on the empty field of "Serial ID", the iButton key ID will be detected by the system and be automatically entered.

*First Name	*Last Name	*User Type	*Serial ID	*Key Code	*Status	Department	Title	Address
Nolan	White	KeyCode		4321	Active			
Paul	Johnson	KeyCode		1234	Active			
Rob	Smith	iButton	BF0000F64BCC601		Active			

To Add Keycode User:

1. Check the Key Code User and click ok.
2. Type in user code under Key Code field

3. Enter the remaining User profile information as follow:

- **First name:** Input the first name of the key owner.
- **Last name:** Input the last name of the key owner.
- **Status:** Active or Inactive (reserve for future use) User. We suggest not deleting any existing user for security reason. User can change the key status from Active to Inactive for a lost key or left employee.
- **Department:** User can either select the pre-input Department name from the pull down list, or input a new name in the field. The new name will be saved to the Department list once the data saved.
- **Title, address:** Can be entered as the key owner profile; photo of the owner can be uploaded to the program.



4. After input all the users, click the  Button and all user keys/codes will be stored.

Step 2: Assign iButtons & User Codes to Lock

Now that we've set up our users in the software, now we need to transfer this information over to the lock.




1. Go to the Mission Management Menu and Select the [Single-Lock Key Assignment](#) menu.

Lock Name:	<input type="text" value="test"/>	Lock Location:	<input type="text" value="test"/>					
Query By								
<input type="checkbox"/> First Name	<input type="text"/>	<input type="checkbox"/> Department	<input type="text"/>					
<input type="checkbox"/> Last Name	<input type="text"/>	<input type="checkbox"/> Status	<input type="text"/>					
 Query								
Selected Key List								
	First Name	Last Name	Time Shift	Activation From	Expiration To	Exceptional Data	Selected	User Type
<input checked="" type="checkbox"/>	11	11	No Limit	6/1/2006	9/1/2006	<input type="checkbox"/>	<input checked="" type="checkbox"/>	iButton
<input type="checkbox"/>	22	22	No Limit	6/1/2006	9/1/2006	<input type="checkbox"/>	<input checked="" type="checkbox"/>	KeyCode
<input type="checkbox"/>	33	33	Time Shift 5	6/1/2006	9/1/2006	<input type="checkbox"/>	<input checked="" type="checkbox"/>	iButton
<input type="checkbox"/>	44	44	Time Shift 6	6/1/2006	9/1/2006	<input type="checkbox"/>	<input checked="" type="checkbox"/>	iButton
<input type="checkbox"/>	66	66	Time Shift 3	6/1/2006	9/1/2006	<input type="checkbox"/>	<input checked="" type="checkbox"/>	iButton


2. Select the Lock Name from lock list
3. Change the time shift if needed (see Section 3: Advanced Access Control Management, #1 for more information on setting up time shifts)
4. Check the selected box for each code or iButton you want to assign to the lock
5. Snap programming key into iWire.
6. Hit "Issue Key"
7. Complete the mission by touching the programming key to the lock reader, wait till hear a double beep.

3. Remote User Code Generation

1. Click on the “Remote Code” icon to enter the code generation screen.




2. Click in Lock Name field to select your lock. The lock select window will pop-up.



3. Select your lock from the list.


- Highlight your lock and then hit the “Select” button. If your lock does not appear automatically, hit the “Query” button and your lock will appear.



4. Fill in Guest Information.


- Fill in the Guest First, and last name. For “Code Type” specify whether the code is a one time service code (to be used only once and then locked out) or temporary code. If temporary, then fill out length of stay information.

5. Select the starting date and ending date that you want to provide access to the property.




6. Click on “Select Check In/Out Time” to change access times.

You can create up to 4 pre-determined check-in/out times. To set the check in/out times, select the group you want to change and click “Modify”. Make the changes to the Check In/Out times and then click “Save”. To finish the process, select the group you want to use and hit “Select.”



7. Finally, select the “Create Code” button to generate your temporary code.



The 8 digits numerical Access Code will be generated by the software. If the remote code duration time is more than 30 days, then the access code will be 10 digits.

- Your guest will then enter the access code followed by the # key to unlock the door.
- Up to 4 Access Code can be created during one overlapping period.

❖ **Sub-Access Codes**

Your guest can enter a sub-access code (shorter code) during their stay. Here are the steps to set the sub-access code :

- Press the "*" key till a solid green light appears on the iButton reader.
- Enter the Access code followed by the # key on the lock keypad. The green light will be flashing.
- While the light is flashing, punch in a desired code (1 to 6 digits) followed by the "#" key. Up to 10 sub-access codes could add to each lock.
- Wait till green light stop blinking or enter "*" to exit the setting. punch in the sub-access code you just assigned followed by "*" key to unlock the door.

❖ **One Time Service code**

Up to 16 one time service codes can be generated within the same time window.


Section 3: Advanced Access Control Management

1. Time Shift Setting

This function is used to restrict certain users/personnel from entering the facility or area during off-hours. For example, you could set up a user so that they can only gain access Monday – Friday from 8AM to 6PM. To set up a Time Shift Schedule:




1. Go to the **Time Shift Setting** window within the Setting Menu.
2. In the Time Shift Setting window that appears, you will notice there are 16 Time Shift Groups in total and up to 7 settings in each group. The first group is No Limit. This is a default setting for each new key and it cannot be modified.
3. To add or modify each Shift Setting in a time group, do the following steps:
 - i. Select the group number from the left side window (Time Shift 2 in this example),
 - ii. Click on Add or Modify or Delete button to edit the settings in the right side window.



- iii. Set the Begin, End Time, and Day of the week.
- iv. Hit Save – Now you have set one day's schedule within the Time Shift. To set the shift for more days, repeat steps ii & iii above.

Here is the example for *Time Shift Group* :

This company wants to set the Group 2 Shift to access from Monday to Friday 8:00am to 7:00pm, and no access on Saturday and Sunday.



4. Now assign Time Shift Groups to each user you have set up. This is done in the Lock Key Assignment Menu. For more information, review Section 2, #2: User Setup: Issuing Permanent Codes and iButtons.

2. Time Lock Operation Setting

This function is used to set the lock itself to automatically unlocked, locked, storehouse mode, or classroom mode at specific time. For example, if you wanted the lock to be unlocked during business hours on Monday through Friday, that can be done in the Timed Operation Setting section.

Step 1: Create Time Operation Setting in Software



1. Go to the **Timed Operation Setting** window within the Setting Menu.
2. You will notice there are 16 Timed Operation Groups in total, and up to 16 settings in each group. The first setting by default is No Limit Classroom Mode (The lock will stay at Passage mode all the time.) The second setting by default is No Limit Storehouse Mode (the lock will stay locked mode all the time).

3. To set up a new Lock Status group, select a lock group (like Lock Status 3)



4. Click the **Add** to add a new setting for the group.
5. Select the Begin Time. Then select the Lock Status and the days of the week you want this status to apply. There are four lock statuses the user can choose:

Begin Time:	0:00:00	<input checked="" type="checkbox"/> Su															
Lock Statue:	Classroom Mode	<input type="checkbox"/> M															
		<input checked="" type="checkbox"/> Tu															
	<table border="1"> <tr> <td>BeginTime</td> <td>Classroom Mode</td> <td>Sur</td> </tr> <tr> <td>00:00:00</td> <td>Lock Mode</td> <td>Tru</td> </tr> <tr> <td>02:00:00</td> <td>Unlock Mode</td> <td>Tru</td> </tr> <tr> <td>06:00:00</td> <td>Lock Mode</td> <td>Tru</td> </tr> <tr> <td></td> <td>Storehouse Mode</td> <td>Fals</td> </tr> </table>	BeginTime	Classroom Mode	Sur	00:00:00	Lock Mode	Tru	02:00:00	Unlock Mode	Tru	06:00:00	Lock Mode	Tru		Storehouse Mode	Fals	
BeginTime	Classroom Mode	Sur															
00:00:00	Lock Mode	Tru															
02:00:00	Unlock Mode	Tru															
06:00:00	Lock Mode	Tru															
	Storehouse Mode	Fals															

- Storehouse Mode: In this mode, the Lock will lock back in few seconds (0.1-25.5 seconds).
- Classroom Mode: In this mode, the lock will be in the unlock mode until next valid key touch the reader.
- Lock Mode: In this mode, the lock will automatically lock at the setting time.
- Unlock Mode: In this mode, the lock will automatically unlock at the setting time.

Here is the example for *Lock Status* :

This company wants to set the lock to unlock mode Monday to Friday 8:00am to 5:00pm

Add	Delete	Modify	Save	Cancel	Select	Quit		
Begin Time:	8:00:00 AM	<input type="checkbox"/> Sunday	<input checked="" type="checkbox"/> Monday	<input checked="" type="checkbox"/> Tuesday	<input checked="" type="checkbox"/> Wednesday	<input checked="" type="checkbox"/> Thursday	<input checked="" type="checkbox"/> Friday	<input type="checkbox"/> Saturday
Lock Status:	Unlock Mode							
[Tip: maximum 16 groups for Storehouse/classroom mode and Lock/Unlock mode]								
Begin Time	Lock Status	Sunday	Monday	Tuesday	Wednesday	Thursday	Friday	Saturday
8:00:00 AM	Unlock Mode	False	True	True	True	True	True	False
5:00:00 PM	Lock Mode	True	True	True	True	True	True	True

Step 2: Transfer Lock Operation Settings to Lock




1. Go to the **Lock Setting** screen within the Setting Menu.
2. Click on “Modify”. Then click “Lock Status”.



Serial ID	Lock Name	Lock Location
A70900000B4FBE01	rldEMO	1325 Colorado Blvd.

3. Select the Lock Operation Group you created in Step 1 above. Then hit “Select”.



LockStatusID	LockStatusName
1	No Limit Classroom Mode
2	No Limit Storehouse Mode
3	Lock Status 3
4	Lock Status 4
5	Lock Status 5
6	Lock Status 6
7	Lock Status 7

Begin Time	Lock Status	Sunday	Monday	Tue
8:00:00 AM	Unlock Mode	False	True	True
5:00:00 PM	Lock Mode	True	True	True

4. Now hit “Save” in the upper menu of the Lock Setting window.
5. Final Step – to transfer this information to your lock, simply re-issue any key in the Lock Key Assignment Menu. When you issue a key, the Lock Operation Setting information will be automatically transferred to the lock. To review how to issue keys, see Section 2, #2: User Setup.

3. Activation/Expiration Setting

This function is used to set the activation date and expiration date of valid keys.

GroupID	ActivationDate	ExpirationDate
1		
2	2005-5-2 1:00:00	2005-6-1 1:00:00
3	2005-1-1 1:00:00	2005-1-1
4	2005-1-1	2005-1-1
5	2005-1-1	2005-1-1
6	2005-1-1	2005-1-1
7	2005-1-1	2005-1-1
8	2005-1-1	2005-1-1
9	2005-1-1	2005-1-1
10	2005-1-1	2005-1-1
11	2005-1-1	2005-1-1
12	2005-1-1	2005-1-1
13	2005-1-1	2005-1-1
14	2005-1-1	2005-1-1
15	2005-1-1	2005-1-1
16	2005-1-1	2005-1-1



1. Select the  window within the Setting Menu.
2. The first group is a default setting as No Limit setting. The rest of groups can be set an activation date and expiration date.
3. Select the Group that you want to modify, like Group 2. Then hit Modify in the upper menu to change settings.
4. Modify Activation Date & Time along with the Expiration Date & Time.
5. Hit SAVE in the upper menu to save the settings.
6. Now assign Time Shift Groups to each user you have set up. To do this, review Section 2, #2: User Setup: Issuing Permanent Codes and iButtons.

4. Audit Trial

Click “Mission Management” on the main screen toolbars and select the “Get Audit Trail” Icon.

This step downloads the audit history from locks. Two DS1977 keys are required for downloading 4000 records.

Number of Records from each lock

Number of locks will be audited up to 19

 Issue Key  Close

1. Snap the program key to the encoder and click on “Issue Key” button.
2. A “Write Get Audit Trail key OK” message will pop up. Click OK to close the screen.
3. Unplug the program key and touch the lock’s ibutton reader, you will hear a long series of chirps followed by two beeps.
4. Snap the program key back to the encoder and click “Read key” button. The read key screen will pop up and then audit trail records will roll up on the screen.
5. Click “Save Data” button, the audit trail records will be saved in Database.

5. Exception Date Setting

This function is used to set restrict access during periods such as holidays, facility shutdowns, vacations.

Group ID	Exception Date From	Exception Date To
1		
2	01/01/2008	01/02/2008
3	01/21/2008	01/22/2008
4	02/18/2008	02/19/2008
5	05/26/2008	05/27/2008
6	07/04/2008	07/05/2008
7	09/01/2008	09/02/2008
8	10/13/2008	10/14/2008
9	11/11/2008	11/12/2008
10	11/27/2008	11/28/2008
11	12/25/2008	01/01/2009
12	01/01/2005	01/01/2005
13	01/01/2005	01/01/2005
14	01/01/2005	01/01/2005
15	01/01/2005	01/01/2005
16	01/01/2005	01/01/2005

Group one is unlimited



1. Select the  window from the Settings Menu.
2. The first group set as No Limit default setting. The holidays can be set as a single day or multiple days. The selected user iButton keys or codes will be restricted from access.
3. Select the Group you want to modify, like Group 2.
4. Click the Modify button in the upper menu.
5. Make modifications to the start and end times for this exception setting.
6. Click Save in the upper menu to chance your exception dates.
7. Now assign Time Shift Groups to each user you have set up. To do this, review Section 2, #2: User Setup: Issuing Permanent Codes and iButtons

6. Mission Management

Mission management allows you to perform several different tasks with your lock, like issue Lock Operation Schedules, check settings, change lock time, etc. Each tab within the Mission Management window is described below.

Set Parameter Key | Set Time Key | Get Information Key | Lockout Key | One-off Key | System Code Key | One-off Code Key

This step sets two parameters:

1. Set LED Blink or Not Blink (Not Blink is an energy save mode to extend the battery life)
2. Set Lock Back Delay time in the Storehouse mode. (Default Setting: 5 Second)

Blink Lock Back Delay Time: [0.1 s — 25.5s]

PC Time:

Daytime Saving

Issue Key Close

Set Parameter Key

This mission will set lock parameters, such as LED “Blink”, lock passing time, adjust lock time, and enable “Daylight Saving”.

Set Time Key

This step uses the DS1904 or DS1994 key to set the real time of the lock

Tip: Other than DS1904/1994 real time key, the DS1977 program key can also set the time of the lock. But program key will cause time delay since programming the mission key and programming the lock will take time. We recommend use DS 1904/1994 real time key if the programming process takes more than 3 minutes.

Get Information Key

The Get Information mission is a useful tool to retrieve the existing lock information, such as: Key list, lock time, Time Setting and lock ID, Batteries voltage, etc.

Lockout Key

Set Lockout key to selected locks, the lock will be put in Lockout mode (lock or unlock) and will forbid all the assigned keys/codes to operate the lock. Apply the Lockout key (any Lockout Key) again to release the Lockout Mode. There are two Lockout Modes:

- Lockout and Open: Apply to the door, lock will stay unlock and lockout all the users.
- Lockout and Close: Apply to the door, lock will stay lock and lockout all the users.

Multiple locks can be selected in one key. Use DS1977 for this type of key.

Set Parameter Key | Set Time Key | Get Information Key | **Lockout Key** | One-off Key | System

This step sets the Lockout key to a specified lock.

Open Door Close Door

Serial ID	Lock Name	Lock Location	Selected
▶			<input type="checkbox"/>

One-Off key/One-Off Code

These are two types of One Time Users: one time service key (DS-1977) or codes (up to 10)

One-Off Key

Step1: Select locks from Lock List.

Step2: Issue key.

This key will immediately work on the selected lock one time only. (No need set up on the lock)

Set Parameter Key | Set Time Key | Get Information Key | **Lockout Key** | One-off Key | System

This step issues an One Time Use card for temporary usage.

Serial ID	Lock Name	Lock Location	Selected
▶			<input type="checkbox"/>

One-Off Code

Entering 10 One-off codes in the list, use DS1977 key to issue a programming key and assign the codes to each lock.

Use *Code# to open lock.

Set Parameter Key | Set Time Key | Get Information Key | Lockout Key | One-off Key | System Code Key | **One-off Code Key**

This step issues an One-off Code Key.

Code NO	One-off Code
▶ 1	
2	
3	
4	
5	
6	
7	

System Code Key

System code key will override the system code of the current programmed locks in the event of losing or forgetting your system code. Re-initialize all the locks would be required without the System code Key.

7. Copy Lock Setting

This is a very useful tool when multiple locks have identical setting such as key list and/or timetable. After you enroll all the locks and users into the system, set timetable and assign keys/codes to one lock, then use this lock as model lock.

Select Model Lock: <-Click Here Same Key List Same Time Table

Serial ID	Lock Name	Lock Location	Selected
2D00000809358F00	test1	test1	<input type="checkbox"/>
FA0000106CF05401	test	test	<input type="checkbox"/>
0000000000000000	test2	test2	<input type="checkbox"/>

Step1: Select Model Lock from lock list

Step2: Select "Same Key List" or/and "Same Time Table" to be copied


Step3: Select the lock from the list

Click on the field of "Select Model Lock", and select the lock from the pop up screen. Check the "Selected" boxes and issue the program key. Complete the mission by touching the programming key to each selected lock reader, wait till hear a double beep.

8. History

Lock Audit History

Click "History" and choose "Lock Audit History" from drop down menu, the following screen will pop up:



Here's how to view the saved data:

1. On "Query By" give the time window of the audit records, and check the key words.
2. On "Order By" check the key words of the records order.
3. Click "Query" button, the records will show on the screen.
4. Click "Export" to save a copy of the audit trail and records the information to an Excel file.

Access Code history

All the remote temporary codes and one time service codes will be saved for future reference

Lock Name	Lock Location	First Name	Last Name	Access Code	Code Type	Start Date	End Date	Date Created	Created By
Front Entry	UCA	Jimmy	Jones	31512006	Temp	07/11/2008	07/12/2008	07/11/2008 11:37:39	dallas
Front Entry	UCA	Steve	T.	15702842	Temp	07/12/2008	07/14/2008	07/11/2008 11:38:11	dallas
Front Entry	UCA	Steve	T.	23020337	Once	07/12/2008	07/13/2008	07/11/2008 11:38:32	dallas
Front Entry	UCA	Steve	T.	15697221	Once	07/12/2008	07/13/2008	07/11/2008 11:38:33	dallas
Front Entry	UCA	Steve	T.	33920442	Once	07/12/2008	07/13/2008	07/11/2008 11:38:33	dallas
Front Entry	UCA	Steve	T.	03618091	Once	07/12/2008	07/13/2008	07/11/2008 11:38:33	dallas
Front Entry	UCA	Lou	D	91215219	Temp	07/14/2008	07/20/2008	07/11/2008 11:39:12	dallas
Front Entry	UCA	Bryan	P	01154137	Temp	07/14/2008	07/27/2008	07/11/2008 11:40:18	dallas
Front Entry	UCA	Fangjie	J	93150127	Temp	07/14/2008	08/03/2008	07/11/2008 11:40:50	dallas
Front Entry	UCA	Fangjie	J	50641294	Temp	08/04/2008	08/08/2008	07/11/2008 11:41:13	dallas
Front Entry	UCA	Don	A	73224510	Temp	08/08/2008	08/10/2008	07/11/2008 11:41:50	dallas
Front Entry	UCA	Mike	Pest Control	64609130	Once	08/08/2008	08/10/2008	07/11/2008 11:42:45	dallas
Front Entry	UCA	Mike	Pest Control	98723239	Once	08/08/2008	08/10/2008	07/11/2008 11:43:16	dallas
Front Entry	UCA	Mike	Pest Control	94172757	Once	08/08/2008	08/10/2008	07/11/2008 11:43:16	dallas
Front Entry	UCA	Mike	Pest Control	27404710	Once	08/08/2008	08/10/2008	07/11/2008 11:43:16	dallas
Front Entry	UCA	Mike	Pest Control	05120093	Once	08/08/2008	08/10/2008	07/11/2008 11:43:16	dallas
Front Entry	UCA	Mike	Pest Control	52354351	Once	08/08/2008	08/10/2008	07/11/2008 11:43:17	dallas
Front Entry	UCA	Mike	Pest Control	73053306	Once	08/08/2008	08/10/2008	07/11/2008 11:43:17	dallas
Front Entry	UCA	Mike	Pest Control	04517924	Once	08/08/2008	08/10/2008	07/11/2008 11:43:18	dallas

Query By:

Start Date: 07/11/2008 To 07/11/2008 Lock Name: Guest First Name:

End Date: 07/11/2008 To 07/11/2008 Lock Location: Guest Last Name:

Date Created: 07/11/2008 To 07/11/2008 Created By: Code Type:

Operator Log

When select "Operator Log", the following screen will show:

Time	Logout Time	Name	Login
12:05	2008-08-11 12:04
12:06	2008-08-11 12:04
12:07	2008-08-11 12:04
12:08	2008-08-11 12:04
12:09	2008-08-11 12:04
12:10	2008-08-11 12:04
12:11	2008-08-11 12:04
12:12	2008-08-11 12:04
12:13	2008-08-11 12:04
12:14	2008-08-11 12:04
12:15	2008-08-11 12:04
12:16	2008-08-11 12:04
12:17	2008-08-11 12:04
12:18	2008-08-11 12:04
12:19	2008-08-11 12:04
12:20	2008-08-11 12:04
12:21	2008-08-11 12:04
12:22	2008-08-11 12:04
12:23	2008-08-11 12:04
12:24	2008-08-11 12:04
12:25	2008-08-11 12:04
12:26	2008-08-11 12:04
12:27	2008-08-11 12:04
12:28	2008-08-11 12:04
12:29	2008-08-11 12:04
12:30	2008-08-11 12:04

Query By:

Login time: 2008-7-21 To 2008-7-21 Login Name:

Logout Time: 2008-7-21 To 2008-7-21 Logout Location:

View:

Login Time Logout Time Name Login

Use the same method to manage the operator log and audit the operators' activity.