





# **User's Guide**


This user's guide contains the product warranty certificate. Be sure to read this user's guide carefully before use.

**DIB-850** 





www.biobidet.com



# CONTENTS

1.	Safety Precautions	4
2.	Product Features · · · · · · · · · · · · · · · · · · ·	8
3.	Parts and Configuration	9
1	Installation · · · · · · · · · · · · · · · · · · ·	
5.	Trial Operation	16
6.	Disassembly of Product · · · · · · · · · · · · · · · · · · ·	17
7	Operation	10
Ο.	Settings	23
9.	Maintenance & Cleaning	25
10.	Troubleshooting	27
	Product Specifications · · · · · · · · · · · · · · · · · · ·	
	Memo ·····	
13.	Warranty Information · · · · · · · · · · · · · · · · · · ·	31



THIS UNIT WAS MANUFACTURED FOR HOUSEHOLD USE ONLY. READ ALL OPERATING INSTRUCTIONS BEFORE INSTALLATION.

#### Notes

- 1. This product should be installed according to this manual.
- 2. Please read this manual carefully and install properly.
- 3. Please save this manual and place in easily accesible location.
- 4. Do not attempt to service this appliance yourself. Doing so will void warranty.



# Ol. Safety Precautions

## **IMPORTANT SAFETYGUARDS**

When using electrical products, especially when children are present, basic safety precautions should always be followed,

#### READ ALL INSTRUCTIONS BEFORE USING

- In the case 120V 60Hz: Power supply must be a 15 Amp GFCI outlet.
- The electrical cord must be connected to a GFCI outlet.
- The GFCL outlet should be 1ft. above the floor.
- Install only in well-ventilated areas to avoid excess humidity.
- Do not install in narrow toilet stalls or in shower stalls.
- Install only where direct contact with water is minimized.
- Do not install near any heat source
- Avoid using extension cords if possible. Consult with a certified electrician where extension cords are necessary.

## DANGER – To reduce the risk of electrocution:

- Do not use while bathing.
- $\bullet\,$  Do not place or store product where it can fall or be pulled into a tub or sink.
- Do not place in or drop into water or other liquid.
- Do not reach for a product that has fallen into water. Unplug immediately.

# WARNING – To reduce the risk of burns, electrocution, fire or injury to persons:

- Close supervision is necessary when this product is used by, on, or near children or invalids.
- Use this product only for its intended use as described in this manual.
   Do not use attachments not recommended by the manufacturer.
- Never operate this product if it has a damaged cord or plug, if it is not working properly, has been dropped or damaged, or dipped into water.
   Return the product to a service center for examination and repair.
- Keep the cord away from heated surfaces.
- Never drop or insert any object into any opening or hose.
- Do not use outdoors or operate where aerosol (spray) products are being used or where oxygen is being administered.
- Connect this product to a properly grounded outlet only. See grounding instructions.
- Unplug this product before filling. Fill (reservoir) with water only.

## **SAVE THESE INSTRUCTIONS**


# 1. Safety Precautions


# GROUNDING INSTRUCTION DANGER - Improper use of the grounding plug can result in a risk of electric shock.

This product has a three-prong grounding plug, which must be plugged into an outlet that is properly installed and grounded. In the event of an electrical short circuit, grounding reduces the risk of electric shock by providing an escape wire for the electric current. If repair or replacement of the cord or plug is necessary do not connect the grounding wire to either flat blade terminal. The wire with insulation having an outer surface that is green with or without yellow stripes is the grounding wire. Check with a qualified electrician or service person if the grounding instructions are not completely understood, or if in doubt as to whether the product is properly grounded.

This product is for use on a nominal 120V circuit, and has a grounding plug that looks like the plug illustrated in sketch A in Figure 1. A temporary adapter, which looks like the adapter illustrated in sketches Band C, may be used to connect this plug to a 2-pole receptacle as shown in sketch B if a properly grounded outlet is not available.

The temporary adapter should be used only until a properly grounded outlet (sketch A) can be installed by a qualified electrician. The green colored rigid ear, lug, or the like extending from the adapter must be connected to a permanent ground such as a properly grounded outlet box cover. Whenever the adapter is used, it must be held in place by the screw.





# **02**.Product Features

## dib bidet has the following characteristics:

## Continuous Warm Water Supply

Enjoy continuous warm water throughout the wash cycle.



## Vortex Wash

Soft but powerful water wash for added cleansing benefit.



#### Bubble Wash

Aerated water wash adds cleaning comfort.



## Stainless steel nozzle

For better hygiene, a stainless steel nozzle is applied.



## Pulse & Oscillate

Pulsating wash repeatedly cycles from weak to strong. Nozzle moves back and forth for massage effect.



## Deodorization Function

Deodorizing filter eliminates odors efficiently.



## Energy Saving Function

When activated, Energy Saving Mode will set the heaters to a lower temperature to reduce energy consumption.



## Child Settings

Optimized nozzle position and water pressure for children.



## Touch panel remote control

Convenient touch screen remote control provides easy user interface.




## User Preset

User can preset and store the memory for control settings.




# 03.Parts and Configuration

# Main Body




# 03. Parts and Configuration

# Operation Panel



# Accessories





# 04.Installation


# Order of Installation





















# 04.Installation

## Remote control installation & batteries insertion


Remove the adhesive protection to attach the remote control bracket to the wall or other surface.



Clean the area thoroughly before attaching the bracket.



3 Turn remove over and open the battery compartment. Insert four "AAA" type batteries(included) as indicated inside battery compartment and replace battery cover.




4 Mount remote (optional)
Identify a location in the bathroom for
the remote control that is visible and
reachable from the toilet and mount
remote using double stick tape (included).




When the batteries have reached the end of service life, all LEDs(5points) will blink. Replace the batteries with new AAA size X 4 pcs.

\* Caution Do not use old and new batteries together. This could cause damage or failure of the remote control.




- If the unit does not work after replacing the batteries, unplug and wait for 3 seconds. Plug in again.
  - \*\* After replacing the batteries, ID of the unit will be initialized as "00" (factory initialization ID), and its ID will be equalized ID of the remote control that reaches the unit first. This ID assigning function will be needed to prevent signal interruption if more than 2 units are used at one place. In case of using one unit only, no setting is needed.
  - \* If you want to change the ID, please refer to the page 23. for "Remote Control ID Setting"




# 05. Trial Operation

# **Trial Operation**

Open the water supply valve by turning it counterclockwise.




2 Check that there are no leaks around the hose connection.



- Be sure that the nozzle comes out and retracts when powered on.
- Don't plug the power cord with wet hands. Risk of electric shock.



4 Place your hand on the occupied sensor of the seat. The unit will fill with water. Check if water comes out from drain hold next to the nozzle for 1~2 seconds.




# 06. Disassembly of Product

# **Disassembly**

Unplug the power plug from the outlet.




Close the water supply valve by turning it clockwise, completely drain out the toilet water tank, release the nuts at bidet body of the bidet hose, and then remove them from the main body.



3. Press the release/drain button on the side of bidet, completely drain the water out of the main body, While pressing the button, pull the main body forward, and then remove it from the toilet.




Release the nuts, and then remove the brackets from the toilet.




# 06. Disassembly of Product


# 07.Operation


# Remove bidet hose, toilet-use hose






# Open the water supply valve by turning it counterclockwise.








# **Basic Operation Method**



Deodorization function starts automatically.



- Press POSTERIOR, FEMININE, VORTEX WASH buttons.
- Selected function can be used as described. (When selecting VORTEX WASH function, Oscillate function cannot be used.) (when selecting Child function, VORTEX WASH function may not operate)
- b dib's specialized water spray in VORTEX WASH function enters into rectum, and then helps relieve constipation and fecal stasis.
- Unless STOP button is pressed after POSTERIOR and FEMININE function, the dryer will start automatically.



## Press the DRY Button.

- Dryer temperature is adjustable. (5 levels)
- Selected function may be used for up to three (3) minutes.
- Dryer effect will be improved if you wipe the moisture lightly before operating the drying function.






# 4 Press the STOP Button.


- ▶ Selected functions stop.
- Press "STOP" on the side control panel for 3 seconds to turn off the unit.




# 07.Operation

# Wide Clean (Oscillation) When pressing the Wide Clean button during the operation of POSTERIOR and FEMININE, nozzle will move back and forth to wash a wider range. When pressing the CHILD button during the operation of Wide Clean, the nozzle position can be adjusted in 5 positions. Wide Clean function will not operate during the operation of VORTEX WASH. Wide Clean function will not operate during the operation of VORTEX WASH.







# **Basic Operation Method**

# CHILD Function Press the Child button to activate. Nozzle position will be one level n

Nozzle position will be one level move forward than normal.

Water pressure will be one level weaker than normal.

Seat temperature will be one level lower than normal.

VORTEX WASH will not operate while Child mode is activating.




## Seat Temperature Control

Temperature of seat can be adjusted to the desired level by pressing Seat temp. button.

Room temp – Low – Middle - High





Temperature of water can be adjusted to the desired level by pressing Seat temp. button.

Room temp - Low - Middle - High



# 12 Energy saving modes

Automatic energy save mode

- -This mode will be activated by pressing the Energy Saving button until yellow LED lamp lights on.
- Seat will be kept at 32°C.

#### Smart energy save mode

- -This mode will be activated by pressing the Energy Saving button until green LED lights on.
- Seat temperature will be kept at 32°c. when it is not occupied, and raise the temperature back to preset level according to memorized time of use.
- It may take  $5 \sim 7$  days to let the unit memorize the usage pattern.

#### Cancel energy save mode

- Press the Energy Saving button until LED is off to release the energy save modes.
- This unit adopts the instant heating technology for water heating and does not consume energy for water heating when it is in stand by mode.

# 07.Operation

# 08.Settings

## 13 Deodorizing function

- When sitting on the seat, deodorizing function starts automatically.
- Speed of deodorizing fan can be controlled. (refer to the User setting facilities, P.22)
- After leaving the seat, the deodorizing function will operate for 1 additional minute.

# 14 Low temperature burn protection

➤ To reduce the chance of low temperature burns, the seat has a seat heater auto adjustment function which turns on low temperature (32°C, 90°F) when user sits on the seat for more than 15 minutes consecutively.

## (T) User Preset

Nozzle position, water pressure, dry/water/seat temperature can be preset and stored for 2 different users.

#### How to preset

- 1) Adjust nozzle position, water pressure, dry/water/seat temperature to your preference.
- 2) Preset 1: Press Stop and ◀ (nozzle forward) simultaneously for 3 seconds.



For 3 seconds

Preset 2: Press Stop and ▶ (nozzle backward) simultaneously for 3 seconds.



For 3 seconds

3) Press the "Stop" button or just wait. Red activating indicator will blink for 5 seconds when setting is completed.



#### Using the Preset Feature

- 1) Press selected preset button.
- Preset nozzle position, water pressure, and temperatures will be activated.



## 8-1. User setting with the remote control

•:	Seat Switch	'Off' S	tatus	○: Seat S	witch '(	On' Statı	ıs 🕦 :	Regard	dless of Or	n/Off
No	Function	Seat Status	Switch (	Operation			Description	on		Initial Status
1	Selecting/ Cancelling Deodorization	•	Press the "Stop" and "Energy saving" for 3 seconds. Then adjust the fan speed by pressing "-" or "+" button. Leave the remote control alone for 5 seconds to complete the setting.		Level  Default  0  1  2  3		Unoccupied High Off Low High	Display of activating indicator Blinking Blinking Blinking Blinking	Display of Energy saving (blinking) Red Off Blue Purple Red	High speed in both modes
2	Setting the ID of remote control	•	Wide Clean"  Press the "Wide Clean" button for 3 seconds. Then set the ID 0~3 by pressing "-" or "+." Leave the remote control alone for 5 seconds to set the ID.		Level  Default  0  1  2  3	Display of indi Blin Blin Blin	king king	(blir	Energy saving sking)  -  Off lue  urple	ID"0"

# 08.Settings

# 09. Maintenance & Cleaning

## 8-2. Extra functions with side contol panel

•:	Seat Switch 'Off' S	Status	: Seat Switch 'On' Sta	tus   Regardless of On/Off
No Function Seat Status		Switch Operation	Description	
7	Manual Nozzle		Press "Posterior" for longer than 3 sec.	Nozzle will move forward for cleaning.
	Cleaning		Press "STOP"	Nozzle will retract and clean itself.
2	Power off	•	Press "STOP" for 3 sec.	Press one of "Stop", "Posterior" or "Feminine" to power on.
3	Factory Default Setting	•	Press "STOP" for longer than 5 sec.	All setting will be initialized.
4	Selecting/Cancelling Silent Mode	•	Press "Feminine" for longer than 3 sec.	To on/off the chime sound.

#### Manual nozzle cleaning

- Press POSTERIOR (on the side control panel) for longer than 3 seconds, and then nozzle will extract and stop (for 2 minutes).
- (2) Clean the nozzle with an unused toothbrush, etc., and press STOP (on the unit's side control panel). Then the nozzle will retract.






## Cleaning of Bidet Body

- Exterior surface of bidet is made of plastic material, which may be damaged by scrubber, chemicals, etc.
- Wipe the surface with a soft damp cloth. Do not spray water directly onto the surface.
- Clean the body after removing the power plug from the outlet, Be sure no water splashes onto the power plug or outlet.
- 4 Do not touch the power outlet with wet hands. Risk of electric shock.



## Draining of remaining water

- Remove the power plug from the outlet.
- Cloe the water feed valve by turning it counterclockwise.
- 3 Press the button on the side of main body to drain the water.





# 09. Maintenance & Cleaning

# 10.Troubleshooting

#### Maintenance during winter season

- Insert the power plug into the outlet and be sure if the power is supplied.
- When the dib will not be used for a long time (more than a few days), close the water shut off valve and drain the water from the bidet.





## \* Please check the following points before requesting the repair of the product.

Problem	Check list			
The bidet is not working	<ul><li>Check if the power plug is not connected.</li><li>Check for power failure.</li></ul>			
Water does not spray	<ul> <li>Check if the water supply is suspended.</li> <li>Check if water supply valve is locked.</li> <li>Check if nozzle is locked by foreign materials.</li> <li>Check if connection hose is bent.</li> </ul>			
Water pressure is low	• Check of the water pressure is set at too low level.			
Water is not war enough	<ul><li>Check if its temperature is set at 'off' or 'low'</li><li>Check if energy save mode is on.</li></ul>			
Seat is not warm enough	<ul><li>Check if its temperature is set at 'off' or 'low'</li><li>Check if energy save mode is on.</li></ul>			
Vortex wash is not operated	<ul><li>Check if it is set on CHILD mode.</li><li>Check if energy save mode is on.</li></ul>			




# 111.Product Specifications

Item			DIB-850			
Rat	ed Voltage	e	AC 120V,60Hz			
Max. Con	sumption	Power	1270W			
Powe	r Cord Len	gth	4ft.			
Water Feed Method			Directly Connected to Water Pipe			
Wat	ter Pressur	e	9.9 ~ 106.6psi			
		Posterior	0.16gal/min			
	Feeding Volume	Feminine	0.16gal/min			
		Vortex wash	0.16gal/min			
Wash	Water Pres	ssure Control	5-Step Control			
	Temp.	Control	Room Temp. ∼ 100°F			
	Hea	t Capa.	1200W			
	Safety	/ Device	Temp. Fuse, Thermo Switch			
	Temp. Control		Room Temp. ∼ 107°F			
Heated Seat	Heate	er Capa.	55W			
	Safety Device		Temp. Fuse			
	Temp.	Temp. Control Room Temp. ~ 122°F				
Dry	Heater Capa.		250W			
	Safety	Device	Temp. Fuse, Bi-metal			
Deodorization			Catalytic Deodorization			
Product Dimension			15.9"(406) x 20.8"(528) x 6.5"(165)			
inch(mm)			15.9"(406) x 19.5"(496) x 6.5"(165)			
Product Weig	ght Elongated		10.8 (4.9kg) / 17.4 (7.9kg)			
∦lb(kg)		Round	10.6 (4.8kg) / 17.2 (7.8kg)			

## ■ Dimension diagrams

inch (mm)



# 13. WARRANTY INFORMATION

## - WARRANTY -

- 1. We hereby guarantee the product as follow in accordance with the regulation of consumer damage compensation.
- 2. In case of failure of the product, please inform the distributor where you purchased the product.
- 3. Product Warranty will be effective for one year from date of purchase.

Customer name		Warranty Period
Model Name		0 (1)
Date Purchased		One (1) year since the date purchased
SER.No.		purchased
Customer's	Name	
Address	Tel.No	
Distributor's	Name	
Address	Tel.No.	

## Regarding Product Warranty Regulation...

- 1. We will repair the product at free of charge in case it was failed under the normal operating condition in accordance with the user's guide during the warranty period.
- 2. Although it is within the warranty period, we will charge the repair service fee etc. (repair + product + travel expense) if it falls under the following cases.

#### Voiding warranty

- 1. Defects occurred from the user's careless handling
- 2. Defects occurred from the usage with incorrect power voltage (E.g., 220V was used to the 110V product.)
- 3. Defects occurred from the improper repair done by the person other than our service engineer.
- 4. Defects occurred from Force Majeure (fire, salt, flood, etc.)
- 5. Failure or damage due to the drop, etc. (user's mis-handling) during the operation after installed
- 6. Defect occurred from the interior modification at user's discretion
- 7. In case the life cycle of the part expired

#### Mail, email or fax the warranty form to:

#### YOUR LOCAL DEALER FIRST where you bought this appliance

If your dealer is unable to assist you

BBC Innovation Corp.

ALGONQUIN IL 60102 F) 847.854.1296

T) 847,458,2334