




Code
2200781601 03
Edit. 02/2016



INSTRUCTION AND MAINTENANCE MANUAL

DRYERS

**QPNC0750 - QPNC1000 - QPNC1250 - QPNC1600 -
QPNC1800 - QPNC2200 - QPNC2500**



READ THIS MANUAL CAREFULLY BEFORE CARRYING OUT ANY OPERATIONS ON THE DRYER.

CONTENTS**PART A: INFORMATION FOR THE USER**

- 1.0 GENERAL CHARACTERISTICS
- 2.0 INTENDED USE
- 3.0 OPERATION
- 4.0 GENERAL SAFETY STANDARDS
- 5.0 DESCRIPTION OF DANGER SIGNALS
- 6.0 DANGER ZONES
- 7.0 SAFETY DEVICES
- 8.0 POSITION OF PLATES
- 9.0 DRYERS ROOM
- 10.0 TRANSPORT AND HANDLING
- 11.0 UNPACKING
- 12.0 INSTALLATION
- 13.0 DIMENSIONS AND TECHNICAL DATA
- 14.0 MACHINE ILLUSTRATION
- 15.0 PARTIAL ROUTINE MAINTENANCE
- 16.0 SCRAPPING THE DRYERS
- 17.0 TROUBLE-SHOOTING AND EMERGENCY REMEDIES

PART B: INFORMATION RESERVED FOR TECHNICALLY SKILLED PERSONNEL

- 18.0 STARTING UP

ATTENTION: THERE IS A COPY OF THE WIRING DIAGRAM INSIDE THE ELECTRIC PANEL

ADDRESSES OF ASSISTANCE CENTRES

In the event of breakdown or malfunction of the dryer, switch it off and do not tamper with it. If repairs are needed, apply only to a technical assistance centre approved by the manufacturer and insist on the use of original spare parts. Failure to comply with the above may endanger the safety of the machine.

INTRODUCTION

Keep this manual with care for future consultation; the use and maintenance manual is an integral part on the dryer. Read this manual carefully before carrying out any operations on the dryer.

The installation of the dryer and all operations involving it must be performed in conformity with the regulations in force concerning electric plants and personal safety.

CHARACTERISTICS AND SAFETY PRECAUTIONS

BEFORE REMOVING THE PROTECTIVE GUARDS TO CARRY OUT ANY MAINTENANCE ON THE MACHINE, SWITCH OFF THE ELECTRIC POWER SUPPLY AND DISCHARGE THE RESIDUAL PRESSURE INSIDE THE UNIT.

ALL WORK ON THE ELECTRIC PLANT, HOWEVER SLIGHT, MUST BE CARRIED OUT BY PROFESSIONALLY SKILLED PERSONNEL.

The manufacturer does not accept responsibility for damage caused as a result of negligence of failure to abide by the instructions given above.

THIS MACHINE IS NOT SUITABLE FOR EXTERNAL INSTALLATION

THIS MACHINE CORRESPOND TO THE ESSENTIAL SAFETY REQUIREMENTS FORESEEN FROM THE EUROPEAN STANDARD (98/37 CE) AND THE RULE EN 292

THE LUBRICATING LIQUIDS AND OTHER EVENTUAL FLUIDS MUST NOT BE DISCHARGED IN THE ENVIRONMENT. THESE POLLUTING AND HAZARDOUS PRODUCTS MUST COMPULSORY BE DISPOSED BY CHARGING AUTHORISED AND SPECIALISED FIRMS ACCORDING TO THE DIFFERENT TYPOLOGY OF PRODUCT.

DIFFERENTIATE THE COMPRESSOR COMPONENTS ACCORDING TO THE DIFFERENT CONSTRUCTION MATERIALS (PLASTIC, COPPER, IRON, OIL FILTER, AIR FILTER ECC...)

1.0 GENERAL CHARACTERISTICS

The dryer is a chilling machine with direct expansion and dry evaporator.

The air to be dried is sent to the heat exchanger in which the water vapor present is condensed: the condensate gathers in the separator and is discharged outside through a drain trap.

2.0 INTENDED USE

The dryer has been built to dry the compressed air for industrial use. The dryer cannot be used in premises where there is a risk of fire or explosion or where work is carried out which releases substances into the environment which are dangerous with regard to safety (for example: solvents, inflammable vapors, alcohol, etc.).

In particular the appliance cannot be used to produce air to be breathed by humans or used on direct contact with foodstuffs. These uses are allowed if the compressed air produced is filtered by means of a suitable filtering system (Consult the manufacturer for these special uses.)


This appliance must be used only for the purpose for which it was specifically designed. All other uses are to be considered incorrect and therefore unreasonable. The Manufacturer cannot be held responsible for any damage resulting from improper, incorrect or unreasonable use.

3.0 OPERATION

The gaseous refrigerant coming from the evaporator (4) is sucked by the refrigeration compressor (1) and it is pumped into the condenser (2). This refrigerant condenses here with the help of the fan (3); and passes through the filter (8) before expanding through the capillary tube (7) and returning to the evaporator where it produces the refrigerating effect. Due to the heat exchange with the compressed air which passes through the evaporator against the stream, the refrigerant evaporates and goes back to the compressor for a new cycle.

The circuit is equipped with a hot gas bypass system for the refrigerant; this intervenes to adjust the available refrigerating capacity to the actual cooling load. This is achieved by injecting hot gas under the control of the valve (9): this valve keeps constant the pressure of the refrigerant constant in the evaporator. The dew point therefore decreases below 0 °C in order to prevent the condensate from freezing inside the evaporator. The dryer runs completely automatically.

DRYER FLOW DIAGRAM



1) REFRIGERANT COMPRESSOR	9) HOT GAS BYPASS VALVE
2) CONDENSER	10) AIR-TO-AIR EXCHANGER
3) MOTOR FAN	11) DEW POINT THERMOMETER
4) EVAPORATOR	12) FAN CONTROL PRESSURE SWITCH
5) DEMISTER CONDENSATE SEPARATOR	13) MAX PRESSURE SWITCH
6) IMPURITY TRAP	14) LIQUID SEPARATOR
7) EXPANSION CAPILLARY TUBE	15) CONDENSATE DRAIN
8) REFRIGERANT FILTER	16) MIN. PRESSURE SWITCH

4.0 GENERAL SAFETY STANDARD

The appliance may be used only by specially trained and authorized personnel.

Any tampering with the machine or alterations not approved beforehand by the Manufacturer relieve the latter of responsibility for any damage resulting from the above actions.

The removal of or tampering with the safety devices constitutes a violation of the European Standards on safety.



ALL WORK ON THE ELECTRIC PLANT, HOWEVER SLIGHT, MUST BE CARRIED OUT BY PROFESSIONALLY SKILLED PERSONNEL.

5.0 DESCRIPTION OF DANGER SIGNALS

				
1) Dangerous electric voltage	2) Air not fit for breathing	3) High pressure	4) Fan rotating	5) Hot parts


6.0 DANGER ZONES

6.1 DANGER ZONES




Risks present on the whole machine

FIG. 2



7.0 SAFETY DEVICES**7.1 SAFETY DEVICES**

1) Cooling fan shield	3) Ground
2) Shield	




ENGLISH

8.0 POSITION OF PLATES

8.1 POSITION OF THE DANGER PLATES (Fig. 4)

The plates fitted on the compressor unit are part of the machine; they have been applied for safety purposes and must not be removed or spoiled for any reason.

Ref.1 - Spare plate Code 1079 9903 48



8.2 POSITION OF THE DATA PLATES (Fig. 4)

Ref. 2) "IN"	Ref. 4) Identification plate
Ref. 3) "OUT"	

9.0 DRYERS ROOM

9.1 FLOOR

The floor must be even and of industrial type; the total weight of the machine is shown in Fig. 5
Remember the total weight of the machine when positioning it.

9.2 VENTILATION


The choice of an appropriate room will prolong the life of your dryer; the room must be spacious, dry, well ventilated and free from dust.

The operating conditions to be complied with are the following:

Min. room temperature: (41 °F)+5 °C (compulsory)	Min. inlet allowed temperature: (37,4 °F)3 °C
Max. room temperature: (113 °F)+45 °C (compulsory)	Max. inlet allowed temperature: (131 °F)55 °C
Max. temperature of incoming air: (131 °F)55 °C	Max. working pressure: (188 psi)13 bar

10.0 TRANSPORT AND HANDLING

The machine must be transported as shown in the following figures.



11.0 UNPACKING



CUTTING THE METAL STRAPPING IS A DANGEROUS OPERATION, DO NOT LEAVE THE CUT PIECES IN THE ENVIRONMENT.

After removing the packing, ensure that the machine is unbroken and that there are no visibly damaged parts.

If you are in doubt, do not use the machine but call your distributor's service department or to dealer.

The packing material (plastic bags, polystyrene foam, nails, screws, wood, metal strapping, etc.) must not be left within the reach of children or left in the environment, as they are a potential source of danger and pollution. Dispose of these materials in the approved collection centers.

12.0 INSTALLATION

12.1 POSITIONING

After unpacking the equipment and preparing the dryers room, put the machine into position, checking the following items:

- ensure that there is sufficient space around the machine to allow maintenance (see Fig. 6).

ENSURE THAT THE OPERATOR CAN SEE THE WHOLE MACHINE FROM THE CONTROL PANEL AND CHECK THE PRESENCE OF ANY UNAUTHORIZED PERSONS IN THE VICINITY OF THE MACHINE.




FIG. 6

12.2 ELECTRICAL CONNECTION

- Check that the supply voltage is the same as the value indicated on the machine data plate.
- Check the condition of the line leads and ensure that there is an efficient ground lead.
- **Ensure that there is an automatic cut-out device upstream for the machine against overcurrents, with a differential device (Ref. 1 Fig. 6), wiring diagram.**



ONLY PROFESSIONALLY SKILLED PERSONNEL MAY HAVE ACCESS TO THE ELECTRIC PANEL. SWITCH OFF THE POWER BEFORE OPENING THE DOOR OF THE ELECTRIC PANEL. COMPLIANCE WITH THE REGULATIONS IN FORCE CONCERNING ELECTRIC PLANTS IS FUNDAMENTAL FOR OPERATOR SAFETY AND FOR THE PROTECTION OF THE MACHINE.

12.3 CONNECTION TO THE COMPRESSED AIR NETWORK

Fit a manual interception valve Ref. 1 between the machine and the compressed air network so that the dryer may be isolated during maintenance operations (see figure 7).

Drainage of condensate Ref. 2 Fig. 7 (automatic) are led outside the machine with a flexible pipe that may be inspected. Drainage must comply with the local regulations in force.



ALL DAMAGE DUE TO THE FAILURE TO COMPLY WITH THESE INDICATIONS CANNOT BE ATTRIBUTED TO THE MANUFACTURER AND MAY CAUSE INVALIDITY OF THE GUARANTEE CONDITIONS.

12.4 STARTING UP

See part B of this manual, Chapter 18.0






FIG. 7

13.0 DIMENSIONS AND TECHNICAL DATA



MODD.	L in (mm)	W in (mm)	H in (mm)
QPNC 0750	40,1 (1020)	42,6 (1082)	60,4 (1535)
QPNC 1000	40,1 (1020)	42,6 (1082)	60,4 (1535)
QPNC 1250	40,1 (1020)	42,6 (1082)	60,4 (1535)
QPNC 1600	40,1 (1020)	44,2 (1123)	60,07 (1526)

MODD.	A	B
QPNC 0750	3" GAS F. - CE 3"NPT - cULus	3" GAS F. - CE 3"NPT - cULus
QPNC 1000	3" GAS F. - CE 3"NPT - cULus	3" GAS F. - CE 3"NPT - cULus
QPNC 1250	3" GAS F. - CE 3"NPT - cULus	3" GAS F. - CE 3"NPT - cULus
QPNC 1600	FLANGED (DN 125) FLANGED (Ansi 6")	FLANGED (DN 125) FLANGED (Ansi 6")

MODD.	WEIGHT lb (Kg.)	Freon R404A lb (Kg.)		Nominal Power HP (W)		Nominal Power HP (W)		Bar psi (MAX.)
		50 Hz	60 Hz	50 Hz	60 Hz	50 Hz	60 Hz	
QPNC 0750	717 (325)	11,02 (5,000)	(11,46) 5,200	5,22 (3900)	7,33 (5470)	1,05 (790)	1,67 (1250)	bar 188 (13)
QPNC 1000	738 (335)	10,36 (4,700)	(11,46) 5,200	5,98 (4460)	7,80 (5820)	1,05 (790)	1,67 (1250)	bar 188 (13)
QPNC 1250	771 (350)	12,12 (5,500)	(12,56) 5,700	7,44 (5550)	9,73 (7260)	1,05 (790)	1,67 (1250)	bar 188 (13)
QPNC 1600	837 (380)	14,55 (6,600)	14,55 (6,600)	9,00 (6715)	13,06 (9740)	1,05 (790)	1,67 (1250)	bar 188 (13)



Reference conditions:	V400-3-50	V460-3-60	Limit conditions:	V400-3-50	V460-3-60
Ambient temperature	77 °F (25 °C)	100 °F (38 °C)	Max. ambient temperature	113 °F (45 °C)	113 °F (45 °C)
Inlet air temperature	95 °F (35 °C)	100 °F (38 °C)	Min. ambient temperature	41 °F (5 °C)	41 °F (5 °C)
Working pressure	101 psi (7 bar)	101 psi (7 bar)	Max. inlet air temperature	131 °F (55 °C)	131 °F (55 °C)
			Max. working pressure	188 psi (13 bar)	188 psi (13 bar)

14.0 MACHINE ILLUSTRATION


14.1 GENERAL LAY-OUT

1	Refrigerant compressor	7	Refrigerant filter-dryer
2	Condenser	8	Capillary
3	Fan motor	9	Fan motor pressure switch
4	Evaporator	10	High pressure switch
5	Condensate drain	11	Liquid accumulator
6	Hot gas by pass valve	12	Low pressure switch

FIG. 8



13.1 DIMENSIONS AND TECHNICAL DATA



MODD.	L in (mm)	W in (mm)	H in (mm)
QPNC 1800	40,1 (1020)	82,6 (2099)	60,4 (1535)
QPNC 2200/2500	40,1 (1020)	82,6 (2099)	60,4 (1535)

MODD.	A	B
QPNC 1800	FLANGED (DN 125) FLANGED (Amsi 6")	FLANGED (DN 125) FLANGED (Amsi 6")
QPNC 2200/2500	FLANGED (DN 125) FLANGED (Amsi 6")	FLANGED (DN 125) FLANGED (Amsi 6")


MODD.	WEIGHT lb (Kg.)	Freon R404A lb (Kg.)		Nominal Power HP (W)	50 Hz	60 Hz	Nominal Power HP (W)	50 Hz	60 Hz	Bar psi (MAX.)
		50 Hz	60 Hz							
QPNC 1800	550 (1212)	23,14 (10,500)	23,14 (10,500)	9,11 (6800)	9600 (11,28)	2,11 (1580)	3,35 (2500)	188 (13)	188 (13)	188 (13)
QPNC 2200/2500	600 (1323)	25,35 (11,500)	24,25 (11,000)	13,6 (10200)	12500 (16,7)	2,11 (1580)	3,35 (2500)	188 (13)	188 (13)	188 (13)

Reference conditions:		Limit conditions:		V400-3-50		V460-3-60	
Ambient temperature		Max. ambient temperature		77 °F (25 °C)		113 °F (45 °C)	
Inlet air temperature		Min. ambient temperature		95 °F (35 °C)		41 °F (5 °C)	
Working pressure		Max. inlet air temperature		101 psi (7 bar)		131 °F (55 °C)	
		Max. working pressure				188 psi (13 bar)	

14.1 GENERAL LAY-OUT

1	Refrigerant compressor	7	Refrigerant filter-dryer
2	Condenser	8	Capillary
3	Fan motor	9	Fan motor pressure switch
4	Evaporator	10	High pressure switch
5	Condensate drain	11	Liquid separator
6	Hot gas by pass valve	12	Low pressure switch

FIG. 8a




14.2 COMMAND AND CONTROL PANEL



BEFORE CARRYING OUT THE OPERATION TEST, READ CAREFULLY AND ACQUIRE A GOOD KNOWLEDGE OF THE COMMAND FUNCTIONS.

- Ref. 1) Dew point indicator
- Ref. 2) Stop - Running button - Door block
- Ref. 3) Green voltage indicator - Running
- Ref. 4) Red alarm indicator for:
 - Condensate drain
- Ref. 5) Red alarm indicator for:
 - High / Low pressure
 - Fan motor protection

FIG. 9



15.0 PARTIAL ROUTINE MAINTENANCE



BEFORE CARRYING OUT ANY MAINTENANCE JOBS IT IS OBLIGATORY TO STOP THE MACHINE AND DISCONNECT IT FROM THE POWER MAINS AND FROM THE COMPRESSED AIR DISTRIBUTION NETWORK.

15.1 MAINTENANCE SCHEDULE

These maintenance intervals are recommended for work environments that are not dusty and are well ventilated. For particularly dusty environments, double the maintenance frequency.

Each Week

Condensate drain: Clean the filter of the drain trap

Each Monthly

Condenser: Clean the condenser fins to remove dust.

15.2 CLEANING OF THE AUTOMATIC CONDENSWATER DISCARGER FILTER (Fig. 10)

Clean the filter of the steam trap.

Proceed as follows:


- Close the cock Ref. 1 Fig. 10
- Remove the panel Ref. 5 Fig. 10
- Release the pressure in the dryer by pressing the condensate drain "TEST" pushbutton locate on the drain trap Ref. 2 Fig. 10.
- Switch off the machine. Turn the switch to the STOP Ref. 3 Fig. 10
- Turn on the supply automatic differential switch Ref. 4 Fig. 10



HOT PARTS INSIDE

- Remove Y-strainer plug Ref. 6
- Remove the filter Ref. 7
- Clean the filter Ref. 7 with a jet of air, working from inside to outside
- Install the filter, fix the plug Ref. 7 - 6
- Close the panel Ref. 5

FIG. 10



15.3 CLEANING THE CONDENSER (Fig. 10)

The condenser must be cleaned every month.

Proceed as follows:

- Switch off the machine. Turn the switch to the STOP Ref. 3 Fig. 10
- Turn on the supply automatic differential switch Ref. 4 Fig. 10
- Remove the panel Ref. 8 Fig. 10
- Clean the condenser fins Ref. 1 with compressed air (Fig. 10) **DO NOT USE WATER OR SOLVENTS**
- Close the panel Ref. 8 Fig. 10

16.0 SCRAPPING THE UNIT

If the machine is to be scrapped, it must be dismantled into parts of the same material, to be disposed of according to the local regulations in force.

ALWAYS RESPECT THE REGULATIONS IN FORCE FOR DISPOSING OF OLD OIL AND OTHER POLLUTING MATERIALS SUCH AS INSULATING FOAM, ETC.

17.0 TROUBLE-SHOOTING AND EMERGENCY REMEDIES



ALL WORK MUST BE CARRIED OUT BY PROFESSIONALLY SKILLED PERSONNEL. BEFORE CARRYING OUT ANY MAINTENANCE JOBS IT IS OBLIGATORY TO STOP THE MACHINE AND DISCONNECT IT FROM THE POWER MAINS.

N.B. OPERATIONS MARKED **■■■** MUST BE CARRIED OUT BY PROFESSIONALLY SKILLED PERSONNEL APPROVED BY THE MANUFACTURER

FAULT FOUND	POSSIBLE CAUSES	OBSERVATIONS
1) No compressed air passes through the dryer outlet	1A) The pipes are frozen inside	<ul style="list-style-type: none"> ■■■ -The bypass valve of the hot gas is broken or out-of-calibration -The room temperature is too low and the evaporators piping are obstructed with ice
2) Presence of condensate in the pipings.	2A) The condensate separator does not work correctly 2B) The dryer is working outside its rating 2C) The dryer is working under bad conditions of condensation	<ul style="list-style-type: none"> -Clean the filter from the condensate drain ■■■ -Check the condensate drain -Check the flow rate of treated air -Check the room temperature -Check the air temperature at the drier inlet. -Clean the condenser. ■■■ -Check the operation and the calibration of the press. switch ■■■ -Check that the fan is operating correctly.
3) The compressor head is very hot (> 55 °C)	Make reference to 2B Make reference to 2C 3A) The cooling circuit is not working with the right gas charge	<ul style="list-style-type: none"> ■■■ -Check if there are leaks of refrigerating gas. ■■■ - Charge it again.
4) Motor cuts out on overload	Make reference to 2B Make reference to 2C Make reference to 3A	
5) The motor hums and does not start.	The line voltage is too low. The machine was switched off and on again without leaving enough time for pressure balancing. The motor starting system is defective.	<ul style="list-style-type: none"> -Contact the electric power company -Wait a few minutes before starting the machine again.
6) The machine has stopped and does not restart even after a few minutes.	The thermostatic protection with manual reset has intervened: make reference to 2B-2C-3A. The motor has burnt out	
7) The compressor is very noisy.	Troubles with the internal mechanical parts or with the valves	

PART "B"



THIS PART "B" OF THE INSTRUCTIONS MANUAL IS RESERVED FOR PROFESSIONALLY SKILLED PERSONNEL APPROVED THE MANUFACTURER.

18.0 STARTING UP



BEFORE CARRYING OUT ANY OPERATION ON THE MACHINE, ENSURE THAT THE ELECTRIC POWER SUPPLY HAS BEEN DISCONNECTED
WAIT AT LEAST TWO HOURS BEFORE STARTING UP, AFTER ANY MACHINE MOVEMENT (TRANSPORT OR HANDLING).

18.1 PRELIMINARY CONTROLS

Before starting the dryer, check:

- The connection to the compressed air piping: remember to remove caps on the dryer inlet and outlet.
- The connection to the condensate drainage system.
- That the power supply is right.

18.2 STARTING AND STOP

Start the system before the air compressor starts running and stop it after the air compressor has been stopped. The compressed air piping will be free of condensate only by doing so. The dryer must be kept running during all the time the air compressor is running. **WARNING:** if the dryer is switched off, before starting it again, wait at least 5 minutes in order to allow the pressure to balance.

BEFORE CARRYING OUT ANY MAINTENANCE JOBS IT IS OBLIGATORY TO STOP THE MACHINE AND DISCONNECT IT FROM THE POWER MAINS AND FROM THE COMPRESSED AIR DISTRIBUTION NETWORK.

PRESSURE DISCHARGE PROCEDURE

Proceed as follows:

- Close the cock Ref. 1 Fig. 11
- Remove the panel Ref. 2 Fig. 11
- Release the pressure in the dryer by pressing the condensate drain "TEST" pushbutton locate on the drain trap Ref. 3 Fig. 11
- Switch off the machine. Turn the switch to the STOP Ref. 4 Fig. 11
- Turn on the supply automatic differential switch Ref. 5 Fig. 11
- Close the panel Ref. 2 Fig. 11




FIG. 11

CALIBRATIONS

HOT GAS BYPASS VALVE


N.B. These valves have already been calibrated and they do not require any adjustment. A dew point different from the rated one generally depends on causes which are not attributable to their operation.

Ref. 1) Closing cap

Ref. 2) Adjusting screw

WORKING PRESSURES AND TEMPERATURES OF R404A

SUCTION SIDE OF REFRIGERATION COMPRESSOR		
	Evaporat. Temperat. °F (°C)	Evaporating Pressure psi (bar)
RATED VALUES (Temperat. 68°F (20°C)	35,6 ÷ 37,4 (2 ÷ 3)	R404A 78,3 ÷ 81,2 (5,4 ÷ 5,6)



ORIGINAL PART