M	PROBLEM	POSSIBLE CAUSE	COR	CORRECTIVE ACTION				
g GUIDE	Does not flush	a. Water supply valve closed. b. Supply line blocked. c. Flush valve chain too loose or disconnected.	Open valve and allow water to fill tank. Shut off water supply, disconnect supply line and inspect all gaskets and washers. Reassemble. Also, see Fluidmaster maintenance. (see Step 13) C. Readjust chain length as required.					
HOOTIN	Poor or sluggish flush	d. Shut off water supply. Remove cap and clean as per Step 13. a. Check that refill tube is connected to water control and inserted into tank overflow without being kinked or damaged. b. Open supply valve fully. Be sure that proper supply tube size is used. c. Remove obstruction. Consult a plumber if necessary.						
TROUBLESHOOTING	Toilet leaks Toilet does not	c. Partially cloggied frapway and/or drain pipe and/or vent. d. Supply pressure too low. a. Poor supply line connection. b. Poor bowl to tank/floor connection. a. Flush valve chain too tight, holding flush valve open.	d. Norm a. Revie b. Revie a. Read	d. Normal supply pressure must be at least 20 psi. a. Review Step 9 of installation procedure. b. Review Step 4 through 7 of installation procedure. a. Readiust chain lenoth as needed. Review Step 10.				
Ħ	shut off	b. Flush valve seat and/or flapper worn or deformed. c. Sand or debris lodged in water control.	b. Shut off water supply. Replace flush valve. c. Shut off water supply. Remove cap and clean per Step 13. corrective actions.					
Ŀ	WARNING: Use of in tank cleaning products voids warranty as they may damage parts and cause leakage that may lead to property damage.							
	Repair parts are determined by toilet tank number which can be found marked inside NOTE: "XXX" represents color or trim finish options. Specify when ordering.		tank.	4202.101	4202.500 X	4202.016 WE	4202.151	CRITICAL TANK LEVEL MARK ("C.L.") MUST
	PART NO.	DESCRIPTION		4200	420,	420,	420	BE 1" ABOVE FLOAT # 8
I. [7381031-XXX0A	TRIP LEVER - STANDARD LEFT HAND		~	~	~	~	
ST	034783-XXX0A	BOLT CAP KIT		~	>	٧	~	VALVE FLUSH-VALVE
SIT	7381125-400.007	0A FLUIDMASTER 400A VALVE		~	~	~	~	VALVE WATER LEVEL
TS	7381146-402.007	,			~			ADJUSTMENT 8
ובמו	7381193-201.007				>	~		ADJUSTABLE FLAPPER
\bar{B}	7301021-0070A	TANK COUPLING KIT #253		~	~	~	~	SHANK WASHER
REPAIR	735134-400.XXX	TANK COVER - 12" ROUGH		~	~	~	~	WARD ILLI
	7381146-406.007			~				LOCK NUT THREADED
	7381146-405.007	. ,	APPER)				~	CONE WASHER ————————————————————————————————————
	738570-100.0070			~	~	~	~	COUPLING NUT — UIII CONNECTION
	7381146-401.007					~		П (оссоте: о)
	7381193-203.0070A FLAPPER ASSEMBLY (HET) - 3 INCH			~			~	7301372-100 Rev. B
For further assistance please call: In the USA (800) 442-1902 www.americanstandard-us.com, In Canada (800) 387-0369 www.americanstandard.ca								