

FLUSH VALVE

Installation Instructions:

1. Turn off water supply valve.
 2. Flush toilet and drain tank. Use sponge to remove remaining water.
 3. Remove wing nuts and washers (A) and lift off tank.
 4. Remove tank to bowl gasket (B) & remove locknut (C) with nut or spud wrench, lift out old flush valve.
 5. Reverse process.
- Use caution when re-installing the tank to bowl bolts.
Over tightening the nuts can break the china tank.

VÁLVULA DE DESCARGA

Instrucciones de Instalación:

1. Cerrar el suministro de agua.
 2. Descargue el inodoro y drene el tanque. Utilice una esponja para quitar el agua restante.
 3. Retire las tuercas de ala y las arandelas (A) y saque el tanque.
 4. Desaloje la arandela tanque-taza (B) y la tuerca de seguridad (C) con una llave inglesa y saque la válvula de descarga usada.
 5. Vuelva a armar en sentido inverso.
- Tenga cuidado cuando reinstale los tornillos que sujetan el tanque con la taza. Si aprieta demasiado las tuercas puede romper el tanque.

