

Installation Instructions for 2 Point Entry Lockset Models 5310 & 5320

- 1) Install latch and deadbolt mechanism in door.
- 2) Remove inside knob by loosening set screw with allen wrench (provided).
- 3) Fasten Outside Trim plate to Inside Lock Housing with #8 machine screws (provided). Flat spindle should be horizontal when installing to inside lock housing.
- 4) Install deadbolt cylinder. Use #10 machine screws (provided). Secure to dead bolt mounting plate. Flat spindle should be horizontal when installing.
- 5) Slide inside trim plate over inside lock housing and snap into place. At the same time, engage deadbolt spindle into thumb turn.
- 6) Install inside knob over stem and tighten set screw.
- 7) Fasten Outside and Inside Trim plates to door with #8 wood screws (provided).