

Two Point Lock  
Single Cylinder  
5310



Two Point Lock, Providence  
with Trenton Plate  
(Outside)



Two Point Lock, Providence  
with Trenton Plate  
(Inside)

Two Point Lock  
Double Cylinder  
5320



Two Point Lock, Cortina  
with Trenton Plate  
(Outside)



Two Point Lock, Cortina  
with Trenton Plate  
(Inside)

- Standard Door Thickness: 1 5/8" - 2"
- **Extended** Door Thickness: 2" - 2 1/2"
- Specify Door Thickness when ordering
- Extension Kit not available separately

- Schlage C Keyway
- Standard Door Prep and Installation
- Door Prep 5 1/2" C-To-C

**Installation instructions for Two Point Entry Lockset (Models 5310 & 5320)**

1. Install latch and deadbolt mechanism in door.
2. Remove inside knob by loosening the set screw with a Allen wrench (provided).
3. Fasten outside trim plate to inside lock housing with #8 machine screws (provided). Flat spindle should be horizontal with installing to inside lock housing.
4. Install deadbolt cylinder. Use #10 machine screws (provided). Secure to deadbolt mounting plate. Flat spindle should be horizontal with installing.
5. Slide inside trim plate over inside lock housing and snap into place. At the same time, engage deadbolt spindle into thumb turn.
6. Install inside knob over stem and tighten the set-screw.
7. Fasten outside and inside trim plates to door with #8 wood screws (provided).