

Brass Non-Keyed Plates (passage/privacy)

Colonial Style (8010/8020 & 8711/8811), Belmont Style (8102/8202), Quincy Style (8104/8204 & 8704/8804), Victoria Style (8103/8203), Oval Beaded Style (8105/8205), Rope Style (7109/7209 & 7710/7810), Modern Style (8111/8112 & 8113/8213)

- Standard Door Thickness: 1¹/₄"- 2"
- Standard Components:
 - Privacy Pin (for privacy sets)
 - Inside Passage Half Spindle
 - 1" Wood Screws
 - Threaded Tubes & Machine Screws
- supplied upon request for Hollow-Core Doors*
- Full-Lip Strike Plate

- **Extended** Door Thickness: 2"- 3"
- Extended Components:
 - Privacy Pin w/ Extensions (for privacy sets)
 - Long Inside Passage Half Spindle
 - 1" Wood Screws
 - Threaded Tubes & Machine Screws
- supplied upon request for Hollow-Core Doors*
- Extended Full-Lip Strike Plate

Brass Keyed Plates, Single Cylinder

Colonial Style (8060/8990), Belmont Style (8070), Quincy Style (8080/8980), Victoria Style (8090), Oval Beaded Style (6010), Rope Style (7090/7990), Modern Style (8112/8114)

- Standard Door Thickness: 1¹/₄"- 1³/₄"
- Standard Components:
 - Single Cylinder Tailpiece
 - Inside Passage Half Spindle
 - 1" Wood Screws
 - Threaded Tubes & Machine Screws
- supplied upon request for Hollow-Core Doors*
- 2¹/₄" Deadbolt Mounting Screws
- Full-Lip Strike Plate
- Deadbolt Strike Plate

- **Extended** Door Thickness: 1³/₄"- 2¹/₄"
- Extended Components:
 - Long Single Cylinder Tailpiece
 - Long Inside Passage Half Spindle
 - 1" Wood Screws
 - Threaded Tubes & Machine Screws
- supplied upon request for Hollow-Core Doors*
- 2¹/₂" Deadbolt Mounting Screws
- Extended Full-Lip Strike Plate
- Deadbolt Strike Plate

- **Extended** Door Thickness: 2¹/₄"- 2³/₄"
- Extended Components:
 - Extra Long Single Cylinder Tailpiece
 - Extra Long Inside Passage Half Spindle
 - 1" Wood Screws
 - Threaded Tubes & Machine Screws
- supplied upon request for Hollow-Core Doors*
- 3" & 3¹/₂" Deadbolt Mounting Screws
- Extended Full-Lip Strike Plate
- Deadbolt Strike Plate

Brass Keyed Plates, Double Cylinder

Colonial Style (8160/8991), Belmont Style (8071), Quincy Style (8081/8981), Victoria Style (8091), Oval Beaded Style (6011), Rope Style (7091/7991), Modern Style (8212/8214)

- Standard Door Thickness: 1⁵/₈"- 1³/₄"
- Standard Components:
 - Double Cylinder Tailpiece
 - Inside Passage Half Spindle
 - 1" Wood Screws
 - Threaded Tubes & Machine Screws
- supplied upon request for Hollow-Core Doors*
- 3" Deadbolt Mounting Screws
- Full-Lip Strike Plate
- Deadbolt Strike Plate

- **Extended** Door Thickness: 1³/₄"- 2¹/₂"
- Extended Components:
 - Long Double Cylinder Tailpiece
 - Long Inside Passage Half Spindle
 - 1" Wood Screws
 - Threaded Tubes & Machine Screws
- supplied upon request for Hollow-Core Doors*
- 3¹/₂" Deadbolt Mounting Screws
- Extended Full-Lip Strike Plate
- Deadbolt Strike Plate