

Brass Decorative Deadbolt, Single Cylinder

Style #8 (8466), Arts & Crafts (8454), Rectangular (8468), Saratoga (8458) & Knoxville (8459), Quincy (8478)

<ul style="list-style-type: none"> • Standard Door Thickness: 1³/₄"- 2¹/₈" Standard Components: • Single Cylinder Tailpiece • 2¹/₄" Deadbolt Mounting Screws • Deadbolt Strike Plate 	<ul style="list-style-type: none"> • <i>Extended</i> Door Thickness: 2¹/₈"- 2³/₄" Extended Components: • Long Single Cylinder Tailpiece • 2¹/₂" & 3" Deadbolt Mounting Screws • Deadbolt Strike Plate 	<ul style="list-style-type: none"> • <i>Extended</i> Door Thickness: 2³/₄"- 3" Extended Components: • Extra Long Single Cylinder Tailpiece • 3¹/₂" Deadbolt Mounting Screws • Deadbolt Strike Plate
---	--	--

Brass Decorative Deadbolt, Double Cylinder

Style #8 (8366), Arts & Crafts (8354), Rectangular (8368), Saratoga (8358) & Knoxville (8359), Quincy (8378)

<ul style="list-style-type: none"> • Standard Door Thickness: 1¹/₂"- 1⁷/₈" Standard Components: • Double Cylinder Tailpieces • 2¹/₂" Deadbolt Mounting Screws • Deadbolt Strike Plate 	<ul style="list-style-type: none"> • <i>Extended</i> Door Thickness: 1⁷/₈"- 2⁵/₈" Extended Components: • Long Double Cylinder Tailpieces • 3" & 3¹/₂" Deadbolt Mounting Screws • Deadbolt Strike Plate
--	---

* Part # DB4-COLLAR32 Available for 1³/₈" Thick Doors

Brass Modern Deadbolts, Single Cylinder

Modern Style (8467) & Square Style (8469)

<ul style="list-style-type: none"> • Standard Door Thickness: 1³/₄"- 2¹/₈" Standard Components: • Single Cylinder Tailpiece • 2¹/₄" Deadbolt Mounting Screws • Deadbolt Strike Plate 	<ul style="list-style-type: none"> • <i>Extended</i> Door Thickness: 2¹/₈"- 2³/₄" Extended Components: • Long Single Cylinder Tailpiece • 2¹/₂" & 3" Deadbolt Mounting Screws • Deadbolt Strike Plate 	<ul style="list-style-type: none"> • <i>Extended</i> Door Thickness: 2³/₄"- 3" Extended Components: • Extra Long Single Cylinder Tailpiece • 3¹/₂" Deadbolt Mounting Screws • Deadbolt Strike Plate
---	--	--

Brass Modern Deadbolts, Double Cylinder

Modern Style (8367) & Square Style (8369)

<ul style="list-style-type: none"> • Standard Door Thickness: 1¹/₂"- 1⁷/₈" Standard Components: • Double Cylinder Tailpieces • 2¹/₂" Deadbolt Mounting Screws • Deadbolt Strike Plate 	<ul style="list-style-type: none"> • <i>Extended</i> Door Thickness: 1⁷/₈"- 2⁵/₈" Extended Components: • Long Double Cylinder Tailpieces • 3" & 3¹/₂" Deadbolt Mounting Screws • Deadbolt Strike Plate
--	---