

INSTALLATION INSTRUCTIONS

FLUSH MODEL & INSERT MODEL

Flush:

1. Center vent over duct opening in floor.
2. Glue and blind nail frame to sub floor and install flooring.
3. **DO NOT RUN WHEEL OF SANDER OVER THE VENT FACE!**
4. When fitting vent back into the frame, sand the vent to level it with the floor and frame.
5. Finish vent and floor separately for easy removal.
6. Finish all the exposed surfaces (front and back) before installing.

Insert:

1. Finish all exposed surfaces (front and back) before installing.
2. Remove old metal register and replace with finished wood vent.