

Cut Out Template for 1542 BZ

1. USING FULL SIZE TEMPLATE BELOW LAYOUT AREA TO BE CUT OUT. DRILL $\frac{1}{2}$ " DIA STARTER HOLES IN OPPOSITE CORNERS.
2. USING A SCROLL SAW CUT OUT HATCHED AREA OF TEMPLATE.
3. WHEN MOUNTING INTO WOOD, USE $\frac{3}{32}$ " DIA DRILL AND DRILL (4) MOUNTING HOLES USING TEMPLATE AS A GUIDE.

NOTE: WHEN MOUNTING INTO DRYWALL OR MATERIALS LESS THAN $\frac{3}{8}$ " THICK IT IS RECOMMENDED TO USE THE NYLON WALL ANCHORS PROVIDED. A $\frac{7}{32}$ " DIA. DRILL SHOULD BE USED TO DRILL ANCHOR HOLE.

