



CASEMENT FASTENER

FOR USE ON WINDOWS TO PROVIDE WEATHERTIGHT FASTENING. IDEAL FOR FASTENING LOUVERED AND SMALL DOORS.

INSTALLATION INSTRUCTIONS

TOOLS REQUIRED: Hammer, small chisel, pencil and awl.

1. Position fastener in desired location. Using 7/64" bit, drill holes and secure loosely.

notes and secure roosery.

2. For rim strike application (A) Position strike to align with fastener, mark and secure.

3. For mortise strike application

3. For mortise strike application
(B) - Position strike to align
with fastener. Outline strike
plate and inner cutout (to be

plate and inner cutout (to be mortised). Using chisel mortise out the opening to depth of 1/4".

4. Mark and secure.

MAINTENANCE INSTRUCTIONS

H.B. Ives Solid Brass products have a clear, protective lacquer coating which helps prevent discoloration. Do not use abrasive waxes or cleaners.

ASK FOR OTHER FINE DECORATIVE HARDWARE BY H.B. IVES



WINDOW LOCKS



DOOR



COAT & HAT HOOKS



DOOR BOLTS



CASMNT FASTNR RS. MS CO6683 BRT