



INSTRUCTIONS:

1. PLACE HOLDER ON WALL AND LOCATE THE MOUNTING HOLES.
2. PREPARE MOUNTING HOLES.
3. INSTALL HOLDER.

QTY	SCREW DETAIL
2	#10 X 3/4 OPHSMS



WS65 WALL BUMPER
INSTALLATION INSTRUCTIONS



NOTE: DIMENSIONS IN () ARE MILLIMETERS.

TEMPLATE NUMBER: INST.WS65_0

DATE: 09-01-01