



**INSTRUCTIONS:**

1. OPEN DOOR TO DESIRED POSITION.
2. PLACE STRIKE ON WALL AND HOLDER BODY ON DOOR AS ILLUSTRATED. ROLLER MUST ENGAGE STRIKE SQUARELY.
3. LOCATE THE MOUNTING HOLES.
4. PREPARE MOUNTING HOLES AS NECESSARY.
5. INSTALL BODY AND STRIKE.

**NOTES:**

1. METAL DOORS SHOULD BE PROPERLY REINFORCED WITH 3/16" (5) MINIMUM THICKNESS PLATE.

**STRIKE**

|              | QTY | SCREW DETAILS        |
|--------------|-----|----------------------|
| BODY         | 4   | #14 X 1 1/4" TRPHSMS |
| WS45 STRIKE  | 3   | #10 X 1" FPHSMS      |
|              | 3   | PLASTIC EXP SHIELD   |
| WS45X STRIKE | 1   | 5/16" THREADED STUD  |
|              | 1   | LEAD EXP SHIELD      |
|              | 1   | #10 X 1" FPHSMS      |
|              | 1   | PLASTIC EXP SHIELD   |



WS45 & WS45X AUTOMATIC WALL HOLDER INSTALLATION INSTRUCTION



NOTE: DIMENSIONS IN ( ) ARE MILLIMETERS.

TEMPLATE NUMBER: INST.WS45\_0

DATE: 09-01-01