



Vertical distance between holes

| | Inch | mm |
|---|------|------|
| A | 1.5" | 38.1 |
| B | 3" | 76.2 |
| C | 2.5" | 63.5 |
| D | 10" | 254 |
| E | 5" | 127 |

Total Door Undersizing

Single Square Edge Door – 15/32"
 Single Bevel Edge Door – 1/2"
 Pair of Doors, each leaf, Square Edge Door – 7/16"
 Pair of Doors, each leaf, Bevel Edge Door – 15/32"

Reinforcement recommended for six hole pattern at top and bottom of each leaf of hinge.

Hole Preparation (40 places)

Metal frame:
 Standard self drilling self tapping screws - No drilling required
 Optional thread forming screws - #13 or 3/16" drill

Wood frame:
 5/32" drill, 1.5" deep

IVES 224HD 83" & 85" Concealed Continuous Hinge Profile Template



Note: Dimensions in [] are millimeters

Template Number 829222-00(C)

Date: 11-10-11