

Product Information

Applicable product:	
Roman bath filler	K-18486-4
Optional accessories:	
Cable drain	K-7219
Riser tubes for floor-mount installation	K-18492

Installation Notes

Install this product according to the installation guide.

The distance from the centerline of the K-7219 bath drain to the riser tube centerline is 22" (56.9 cm).

Use 1/2" OD supply line inlets.

