

### Product Information

Applicable product:	
Bath/shower valve trim, sculpted lever handle, NPT spout	K-T10274-4E
Bath/shower valve trim, traditional lever handle, NPT spout	K-T10274-4AE
Bath/shower valve trim, sculpted lever handle, slip-fit spout	K-T10275-4E
Bath/shower valve trim, traditional lever handle, slip-fit spout	K-T10275-4AE
Rite-Temp® valve must be ordered to complete faucet.	
Required accessories:	
Rite-Temp valve <b>OR</b>	K-304-*
HiFlow Rite-Temp valve with stops	K-2971-KS
* For a complete listing of all the Rite-Temp valves, refer to the K-304-* Specification sheet or Roughing-in sheet.	
Optional accessories:	
HiFlow Rite-Temp thin wall installation kit	88526
Forte deep roughing-in kit for Rite-Temp valve (lever handles)	1025388

### Installation Notes

Install this product according to the installation guide.

Install the Rite-Temp® valve according to the valve installation guide.

**NOTICE: Risk of product damage.** Long screws, for installing trim, can damage the K-2971-KS valve. Consult the trim installation guide to verify if the thin wall installation kit (88526) is needed.

Avoid cross-flow conditions. Do not install shut-off device on either valve outlet.

Cap shower outlet if deck-mounted spout, diverter, or handshower is connected to the spout outlet.

Install straight pipe or tube drop of 7" (178 mm) to 18" (457 mm) with single elbow between valve and wall-mount spout.

