KOHLER Roughing-In

K-T5318, K-T5319, K-T5320 REFINIA™ RITE-TEMP_® BATH AND SHOWER VALVE TRIM

Product Information

Applicable product:	
Bath and shower valve trim	K-T5318-4
Shower trim with diverter button	K-T5319-4
Shower trim, less diverter button	K-T5320-4
Mixing valve trim with diverter button – ADA compliant	K-T5321-4
Mixing valve trim, less diverter button – ADA compliant	K-T5322-4
Required accessories:	
Required accessories: Rite-Temp pressure-balancing valve OR	K-304-**
	K-304-** K-2971-**
Rite-Temp pressure-balancing valve OR	

Installation Notes

Install the valve trim according to the installation guide.

Install the Rite-Temp valve according to the installation guide.



CAUTION: Risk of product damage. Long screws, for installing trim, can damage the K-2971-KS valve. Consult the trim installation guide to verify if the thin wall installation kit (88526) is needed.

Avoid cross-flow conditions. Do not install a shut-off device on either valve outlet.

Cap the shower outlet if the deck-mounted spout, diverter, or handshower is connected to the spout outlet.

Install a 7'' (178 mm) to 18'' (457 mm) straight pipe or straight tube with single bath elbow between the valve and the wall-mount spout.



