

### Product Information

Applicable product:	
Shower valve trim – sculpted lever handle	K-T10276-4E
Shower valve trim – traditional lever handle	K-T10276-4AE
Rite-Temp valve must be ordered to complete faucet.	

<b>Recommended Accessories</b>	
HiFlow Rite-Temp thin wall installation kit*	88526
*Required when using the K-306-KS valve in a fiberglass or acrylic installation.	

<b>Required Accessories</b>	
Rite-Temp valve without stops <b>OR</b>	K-304-K
Rite-Temp valve with stops <b>OR</b>	K-304-KS
HiFlow Rite-Temp valve with stops <b>OR</b>	K-306-KS
Rite-Temp valve with PVC connections	K-304-KP

<b>Optional Accessories</b>	
Forté deep roughing-in kit for Rite-Temp valve	1025388

### Installation Notes

Install this product according to the installation guide.

**NOTICE: Risk of damage to the K-306-KS valve assembly.** When using the K-306-KS valve in a fiberglass or acrylic installation, use the thin wall installation kit (88526).

Install Rite-Temp valve according to valve installation guide.

Avoid cross-flow conditions. Do not install shut-off device on either valve outlet.

Cap shower outlet if deck-mounted spout, diverter, or handshower is connected to the spout outlet.

Install straight pipe or tube drop of 7" (178 mm) to 18" (457 mm) with single elbow between valve and wall-mount spout.

