



## Assembly Instruction For 9054

1. Place the glass on the socket, then secured by metal cap and socket ring
2. The another 3PCS as same the step 1

