AWARNING BUT R MAY SHATTER AND CAUSE INJURY IF RROKEN.

MISK OF ELECTRIC SHOCK

Turn power off before servicing - see instrucions.

- Allow bulb to cool before handing - Ensure that no bare wires are exposed outside

INSTALLATION PROCEDURES 1. Turn off power.

Note: All installations should comply with local electrical codes. If you have any doubts concerning installating contact a qualified licensed electrician.

2. Knock out the hole on the back of the fluture through which the wire is supposed to 4b. I highly the strong out of the Somey connector

sticking to the igside surface. 4 Screw in the connector through the metal case.



Do not use excessive force when installing bulb.



6 Drob the 3 wires foliarly white and owner) though the wire tube

7 Push the wires into the appropriate connector: White to white

Green to green it install the future using associated scores.





NAMES OF THE PARTY OF THE PARTY

2. Place finger tip on tab of each diffuser end cap. 3 Side too and diffuser froward

4. Lower that edge of diffuser. CLOSING DIFFUSER

1. Swing edge of diffuser with tabs up toward fature until pegs by tabs slip into sko 2. Slide top and diffuser towards rear of future to lack.

MULE REPLACEMENT INSTRUCTIONS

Re-lamp only with Max. 20 Watt. 120 Volt. TYPE T-4 Gill base serion bulb. 1. Turn the light off and allow time for bulb (lamp) to good before harving.

1. Using a cloth or lowel grapp the bulb firmly and pull bulb out of socket linsert new bulb using a paper lowel or

4 Position the obes less by sliding tabs forward allowing pegs to seet in slots.



Reserved State (Indicate Co. Charles) (Indicate Co. Charles)