

## Installation Instructions Model 39712 CLPC

- 1. Turn breaker off for circuit on outlet where fixture is to be installed.
- 2. Remove mounting bracket from fixture and install to electrical box
- 3. Wire fixture to wires in outlet box. Green wire is for Ground.
- 4. Install fixture to back-plate and tighten 2 nuts so that fixture meets the wall.
- 5. Install crystal strands into fixture.
- 6. Install maximum 40 watt G9 xenon lamps

## WARNING!

Xenon lamps burn hot. Allow 15 minutes after turning off before touching!



