

## Installation Instructions Model 39935BCPC

- 1. Turn breaker off for circuit on outlet where fixture is to be installed.
- 2. Remove mounting bracket from fixture and install to electrical box
- 3. Install combination of stems to achieve desired mounting height.
- 4. Wire fixture using green wire as ground
- 5. Install fixture to mounting bracket and secure by tightening ball nuts.
- 6. Install crystal strands A to top pan on inside of fixture.
- 7. Install maximum 40 watt Xenon lamps included.

## **WARNING!**

Xenon lamps burn hot. Allow 15 minutes after turning off before touching

