



Elemental Edges

CARE & MAINTENANCE

I. WALL BASE & INSTALLATION ACCESSORIES

Initial Maintenance

Wipe off any excess amounts of adhesive that may have come through the seams with a damp cloth. Allow the adhesive on the wall base to thoroughly dry before completing the following initial maintenance procedure.

- Wall Base and Installation Accessories are maintained by hand.
- Wash with a wet cloth or wet mop using a neutral cleaner per directions.
- Rinse with clear water.
- Clean Wall Base and Installation Accessories as conditions and soiling dictates.

Routine Maintenance

- Wall Base and Installation Accessories are maintained by hand.
- Wash with a wet cloth or wet mop using a neutral cleaner per directions.
- Rinse with clear water.
- Clean Wall base and Installation Accessories as conditions and soiling dictates.

II. ARCHITECTURAL WALL BASE

Architectural Wall Base is maintained with regular wiping with a soft, wet cloth. A mild soap may be added to the water. Coarse scrubbing media or harsh cleaning chemicals may damage the surface of the wall base.

III. STAIR TREADS NOTE

Treads become slippery when wet and care must be taken. Appropriate barriers to wet areas and Warning/Caution placards should be used in all instances.

- Allow the adhesive on the installed treads to dry thoroughly for 24 hours before completing the initial maintenance.
- Treads are maintained by hand.
- Damp mop or dust mop to remove dust and debris.

- Clean excessive dirt from the tread using a neutral cleaner. Use instructions on the bottle of cleaner for mixing. Let the cleaner work for 5-10 minutes. Scrub with a soft brush while still wet.
- Wipe up any excess cleaner with a dry cloth per instructions.
- It is not necessary to apply a finish to the stair treads. If a finish is desired, clean with denatured alcohol and allow treads to dry and apply coating per manufacturer's instructions.
- Clean treads as conditions and soiling dictate.

IV. RUBBER NOSING

NOTE: Nosing becomes slippery when wet and care must be taken. Appropriate barriers to wet areas and Warning/Caution placards should be used in all instances.

- Allow the adhesive to cure for 24-48 hours before completing the maintenance procedures.
- Wipe all dust and dirt from the nosing.
- Spray with a pH neutral cleaner.
- Gently scrub with a soft deck brush for stubborn soil.
- Wipe cleaner from nosing with a clean dry cloth.
- Wipe the nosing with clear water and dry off with a dry cloth.
- It is not necessary to apply a finish to the nosing.

V. LANDING TILES

NOTE: Floors become slippery when wet and care must be taken. Appropriate barriers to wet areas and Warning/Caution placards should be used in all instances.

- Allow 24 hours for light damp mopping and 72 hours for wet cleaning.
- Sweep or dust mop the floor to remove any large debris. **NOTE:** Never use oil base treated dust mops.
- Clean with a pH neutral cleaner.
- Apply two cross coats of an industrial strength acrylic sealer. In tight areas, use a microfiber mop. Buffing machine or rotary machine can be used in larger areas.