Installation Guide #IS-SQR8604RK QUOIZEL. For Style SQR8604RK Please go to www.quoizel.com for product cleaning tips. Go to the Care + Maintenance selection. Tools Required: Flathead screwdriver, Phillips screwdriver, pliers, wire cutters, wire strippers, electrical tape, safety glasses. Light Source: (4)A19 Medium Base Bulb 100W Maximum, bulb not included. Estimated Assembly Time: 30-45 minutes Preparation: Identify and inspect all parts before beginning installation. Check package content list and diagrams below to ensure all parts are present. If any parts are missing or damaged, do not attempt to assemble, install, or operate the fixture. Missing Parts? Contact your original place of purchase. 🛆 Warnings and Cautions Turn off electricity at circuit breaker or main fuse box before installation. Consult a licensed electrician if in doubt. These instructions are provided for your safety. It is very important you read them completely before installing the fixture. We strongly recommend that a licensed, professional electrician perform the installation. Disconnect fixture from power source before replacing bulbs. Make sure bulbs are given sufficient time to cool before removal. Package Contents STEP 3 - Install Bulb Figure 3 A. Insert bulb onto socket and screw Crossbar snugly into place. Socket x 1 Fixture Vintage Bulb Your fixture is now assembled С Body (recommended and ready to use. Enjoy! x 1 but not supplied) Shade F x 4 Mounting Cap Installation Optional Shade D Screw С x 4 x 2 A. Remove Socket Collar from Fixture Body (C). Socket STEP 1 - Install Crossbar and Fixture Body B. Place Cap (D) over the Socket, secure by threading A. Pass the supply wires through the Crossbar (A). Attach the D Socket Collar onto Socket. Crossbar (A) to Outlet Box with the head of Green Ground Screw Hand tighten until sung. facing you. Secure it with Outlet Box Screws (not included). Tighten Socket Csollar C. Insert bulb onto socket and until snug. Supply Wires and screw snugly into place. B. Refer to Step 2 for Vintage Bulb Ground Wire D. Place the Optional Shade (E) (recommended wiring connections. over the bulb and thread it C. Attach the Fixture but not supplied) Outlet onto the Cap (D) properly. Body (C) over the Box Crossbar (A) and Your fixture is now assembled secure with Mounting and ready to use. Enjoy! Screws (B). Tighten Optional until snug with Figure 4 Outlet Box Screw Shade Figure 1 screwdrivers. R (not supplied) **STEP 2 - Wire Connections** NOTE: ALL DIMENSIONS ARE ROUNDED UP TO THE NEAREST 1/4" SQR8604RK A. Wrap bare or green ground wire around green ground screw on the FINISH: RUSTIC BLACK crossbar, no less than 2 inches from the end of the wire. Tighten the green ground screw. B. Use standard wire connectors (not included) to make all wire connections. Twist connectors until wires are tightly joined together. Wrap each connection with approved electrical tape and carefully stuff all the connected wires into the Outlet Box. White wire White wire from outlet box from fixture Black wire Black wire from from fixture outlet box (or Red) 4.25" Dia Bare, or Green Ground wire 6" Ground wire from Fixture

visit us on-line at www.guoizel.com

30.5

Released Date: 2019-01-17

Figure 3

from outlet box

©2018 Quoizel Inc.

Green Ground Screw

on the Crossbar