



NEW mounting brackets adjust up to 5" so they will align in thick portion of door frame. (Standards may have to be cut to fit shorter doors.)

STEP 1: Figure 1

Measure center (top) to center (bottom) on inside door frame rails.

STEP 2:

Transfer measurement from **STEP 1** to standards and tighten screws.



STEP 3:

Remove door from cabinet and lay face down on a towel to protect finished surface.

STEP 4: Figure 2

Mark center line of door (side to side)

STEP 5: Figure 3

Position one standard on back of door with slats pointed towards top of door.

STEP 6: Figure 4

Align standard parallel to edge of door using spacing according to Dimension "B".

STEP 7:

Fasten to door panel frame using screws furnished.

CAUTION: Determine thickness of door panel and make sure screws are not too long and do not come thru front of panel.

STEP 8:

Repeat **STEP 6** with other standard. Make sure bottom of both standards are level with each other so shelves hang level.

STEP 9:

Replace door to cabinet and hang spice shelves on standards.

READ THIS FIRST!

NOTE:

The standards can be moved side to side if necessary to clear hardware or partition so shelves will clear opening as door swings open.



2409 Plantside Drive
Jeffersontown, KY 40299
502-499-5835 • FAX: 502-491-2215
www.rev-a-shelf.com