



NOTES:

1. Be sure to check for adequate clearance at back of shelf prior to drilling holes.
2. Template position may be adjusted for a full overlay door.
3. Any inside re-enforcement must be accounted for. (Minimum dimensions noted).