

SCHLAGE®

BACKSET

MEASURE
BACKSET AS
REQUIRED TO
MATCH LOCK
LOCATION
ON PAIR OF
DOORS, OR
OTHER LOCKS
ON PROJECT.
(STD. 2 $\frac{3}{8}$ ")

TWO PILOT
HOLES FOR
#8 WOOD
SCREWS

1 $\frac{5}{8}$ "

F170

DUMMY TRIM

