

Important: Label on back contains important information on your crystal color. Please save in case you ever need to order matching crystal.

D

Trim Diagram \*\*4040TM xintsM

ա

Э



Schonbek Worldwide Lighting Inc., 61 Industrial Blvd., Plattsburgh NY 12901-1908 Tel: 800.836.1892 or 518.563.7500 www.schonbek.com

© 2004 SCHONBEK WORLDWIDE LIGHTING INC., A. SCHONBEK & CO. LTD. WORLDWIDE COPYRIGHT RESERVED



1 Light 3½ x 3½ x 4"

Geometrix<sup>™</sup> is designed by Schonbek with Strass<sup>®</sup> crystal by Swarovski.



This design is the proprietary trade dress/trademark of Schonbek Worldwide Lighting Inc

Please save your trim diagram for future reference.

IMPORTANT: Label on back contains important information on your crystal color. Please save in case you ever need to order matching crystal.





## How to Install MR16 Bulb and Matrix<sup>™</sup> Pendant:

Pendants may be mounted to monorail systems, monopoints or line voltage track by coupling to the quick connect transformer adapter. Attached to the socket is a cable that may be cut on site during installation to any length (see instructions below).

**1** Position the pendant grid against the socket and secure in place by screwing the metal collar onto the socket.

 ${f 2}$  Plug bulb carefully but completely into socket. Use only an MR16 glass covered lamp bulb.

## How to Shorten the Cable:



Cut the cable cleanly with wire cutter to desired length, and slide brass collar over wire. Position collar so that a small section (1/16") of braided wire protrudes from the top of the collar.





braided outer wire back to expose inner wire. Trim 1/8" of insulation from the inner wire with wire stripper.



Screw quick connect into quick connect adapter until it seats. If you adjust the orientation of the pendant, be careful not to loosen the connection.

**8** A For Standard Color trimsets: Hang A and B bead chains first, following the Crystal Color Map. Drop strands of crystal beads through slots in top grid. Make sure to follow A - B pattern shown.

**B** For Premium Color trimsets: Hang A bead chains first, following the Crystal Color Map. Drop strands of crystal beads through slots in top grid.

**9** Grasp C chain of crystal by the top crystal. Slip the chain through side opening of the grid slit. It will nest into position between the top and second crystal.