

BARLOW WALL-MOUNT FAUCET

INSTALLATION INSTRUCTIONS

Before installing, read entire installation instructions. Observe all local building and safety codes.

For the following installation instructions it is assumed that the water supply lines have been installed in the desired faucet location. A $\frac{1}{2}$ " female fitting should be attached to the water supply line and in line with the finished wall.

Unpack and inspect the product for any shipping damages. If you find damages, do not install. Contact Customer Service at 1-866-855-2284. If you need assistance or have questions while installing your faucet, contact Customer Service.

We recommend consulting a professional if you are unfamiliar with installing bathroom fixtures and plumbing. Signature Hardware accepts no liability for any damages to the floor, walls, plumbing or for personal injury during installation.

TOOLS AND MATERIALS:

Teflon Pipe Tape

INSTALLATION

- 1. Wrap Teflon pipe tape around the threaded portions of the wall couplers.
- 2. Thread the wall couplers into the female fittings at the finished wall.
- 3. Thread the escutcheons onto the wall couplers.
- 4. Place the faucet body on the wall couplers. Hand tighten the coupling nuts to secure.
- 5. Finish your installation by attaching the hand shower to the faucet body.
- 6. After all connections have been made, turn on the water supply, check to make sure that all connections are tight (no water should be leaking) and that the hot and cold supplies are working correctly. Turn the faucet on and allow the water to flow through the spout for approximately 60 seconds. Divert the water to the hand shower and allow the water to flow through the hose for an additional 60 seconds.

