SONNEMAN[®]

Important: Always disconnect the power before installing or replacing bulb and before cleaning or other maintenance.

This light should be installed by a licensed electrician

Assembly & Installation Instructions

- 1. Shut off power to outlet box (Fig A).
- 2. Make appropriate electrical connections using wire nuts:
- a.Connect the fixture's hot wire (black) to the black outlet box wire.

b.Connect the fixture's neutral wire (white) to the white outlet box wire. c.Connect fixture's ground wire (green or uncoated) to the ground outlet box wire. If no ground is present in outlet box, connect fixture's ground wire to the mounting plate using the green screw (included).

d. Carefully place connections in outlet box.

3. Place mounting plate over outlet box and secure it with outlet box screws.

4. Attach the backplate over the mounting plate (Fig B)

and tighten with the back plate screws on top.

5. Insert 18W 2G11 base twin CFL in sockets (not included).

- 6. Attached the shade by lining up the keyholes with the keyhole screws
- and pushing the shade down until tight. (Fig C)
- 7. Restore power to fixture.



