

SONNEMAN[®]

A WAY OF LIGHT

Installation Instructions for: Hanover Series Sconces: 3383, 3384

**This light should be installed
by a licensed electrician.**

Assembly & Installation Instructions

1. Shut off power to outlet box.
2. Remove mounting plate from fixture.
3. Attach mounting plate to outlet box using outlet box screws.
4. Make appropriate electrical connections using wire nuts.
Connect the black fixture wire to black supply wire.
Connect white fixture wire to white supply wire.
If there is no green ground wire from the outlet box,
connect the fixture ground wire to the mounting plate
with the green screw provided.
Place connections in outlet box.
6. Attach canopy to mounting plate with
the four mounting screws.
7. Place shade over threaded socket and secure
with shade ring.

