outlet box

canopy screw



Important: Always disconnect the power before installing or replacing bulb and before cleaning or other maintenance.

This light should be installed by a licensed electrician

Assembly & Installation Instructions

- 1. Shut off power to the outlet box. (fig. A)
- 2 Attach the mounting plate to the outlet box, tighten with the outlet box screws.
- 3. Determine the height at which the fixture is to be hung. Screw together stem sections to achieve desired length.
- 4. Make appropriate electrical connections using wire nuts: a.Connect the fixture's live wire (black) to the live outlet box wire. b.Connect the fixture's neutral wire (white) to the neutral outlet box wire. c.Connect fixture's ground wire (green or uncoated) to the ground outlet box wire. If no ground is present in outlet box, connect fixture's ground wire to the mounting plate using the green screw (included).
 - d. Carefully place connections in outlet box.
- 5. Attach canopy to mounting plate and secure with canopy knobs.6. Attach glass diffuser to the metal frame, tighten with the plastic washers and screws.
- 7. Install A19 medium base bulb (not included).
- 8. Install the 50W MR16 bulb (included), using the provided suction cup.
- Install the shade by placing over the bulb and set into the metal frame.Snap the shade into the metal clips to secure (Fig B).
- 10. Restore power to the fixture.

CARE INSTRUCTIONS

Dusting — Use a clean, dry cloth. Cleaning — To protect the finish, avoid any harsh abrasives or chemicals.



