SONNEMAN[®]

Assembly Instructions for item : 6016 Puri Series - Floor Lamp

Important: Always unplug the power cord before installing or replacing bulb and before cleaning or other maintenance.

LAMP INSTALLATION AND ASSEMBLY

- 1. Attach lower stem to base and turn until tight.
- 2. Attach upper stem to lower stem and turn until tight.
- 3.. Place glass diffuser on metal plate.
- 4. Install A19 bulbs. (not included)
- 5. Place shade on threaded stem.
- 6. Place metal diffuser on shade. Locate upper threaded stem through hole in diffuser.
- 7. Secure with finial.
- 8. Plug in cord and switch is under metal plate.

CARE INSTRUCTIONS

Dusting — Use a clean, dry cloth. Cleaning — To protect the finish, avoid any harsh abrasives or chemicals.



