

Important: Always disconnect the power before installing or replacing bulb and before cleaning or other maintenance.

Assembly & Installation Instructions

1. Attach base to nipple at the bottom of stem, and secure with lock washer and hex nut by using spanner.
2. Pull the excess cord out of the base.
3. Install 75W G9 Xenon bulb. (included)
4. Attach the explosion guard to the socket cup, and secure with screw.
5. Plug in the cord and the high-low-off switch is located on shade holder.

CARE INSTRUCTIONS

Dusting — Use a clean, dry cloth.

Cleaning — To protect the finish,
avoid any harsh abrasives or chemicals.

