

ASSEMBLY AND INSTALLATION INSTRUCTIONS

OD39006

WARNING: BE SURE TO SHUT OFF POWER AT THE MAIN FUSE OR CIRCUIT BREAKER BOX BEFORE INSTALLING OR SERVICING THIS FIXTURE.

NOTE: Before installing, consult local electrical codes for wiring and grounding requirements.

1. Attach nipple(-a) to the mounting strap, then secure it with a washer and hex nut.
2. Attach the mounting strap to the outlet box by using two mounting screws.
3. Carefully take the glass shade out of the frame, then discard the bubble bags.
4. Secure the loop to nipple(-b).
5. Choose the length of the chain you need, then weave the fixture wire and the fixture grounding wire through the chain links. Then connect one end of the chain with the loop by using the loop lock.
6. Secure the top loop to nipple(-a).
7. Thread the fixture wire and fixture grounding wire through the collar, canopy, top loop, nipple(-a) and mounting strap.
8. Connect the other end of the chain with the top loop by using the loop lock.
9. Pull out the outlet wires and house grounding wire from the outlet box. Make wire connections using the wire nuts:
 - The smooth wire (marked) from the fixture to the black wire from the power source.
 - The ridged wire (unmarked) from the fixture to the white wire from the power source.
 - Attach the fixture grounding wire to the mounting strap with the green grounding screw. Then connect it to the house grounding wire with a wire nut.
 Carefully tuck the wires back into the outlet box.
10. Attach the canopy to the mounting strap by inserting the top loop, then secure it with the collar.
11. Put the glass shade into the frame carefully.
Note: Place the bigger side marked an arrow up.
12. Secure the buckles to fix the glass shade by using three pads and three set screws. (See Fig. 1)
13. Attach the candle tubes to the sockets, then install bulbs (not included). See relamping label at socket area or packaging for maximum allowed wattage.
14. Secure the headless screws into the frame.
15. Attach the frame upward to the dome by inserting the headless screws, then secure them with the ball nuts.
16. Turn on the power at the main fuse or circuit breaker box.

