

# Low Voltage Surface Mounts LP-Fixtures Installation Instructions

## CAUTION:

Always turn off power at fuse box prior to installation to prevent electrical shock.

For installation by a qualified electrician.

Line voltage wire must be 12awg BX or Romex wire.

Install over a standard 4 inch junction box.

All wires must be contained in the junction box.

## TO HARD WIRE:

1. Loosen the three canopy screws and separate the canopy cover from the base plate.
2. Remove knock out from the base plate.
3. Guide the two black wires and green grounding wire from the fixture through the knock out in the base plate and into the Junction box.
4. Connect with line volt wires from the junction box to fixture wires, with wire nuts (Note fixture wires are not polarized) .
5. Connect green grounding wire from junction box (may be bare copper wire) to green wire from fixture.
6. Attach the base plate to a junction box using the key hole slots.
7. Mount the canopy to the base plate, and tighten the three screws loosened earlier.

