

# KOHLER<sup>®</sup>

## Roughing-In

K-T13134, K-T13135  
PINSTRIPE<sup>®</sup>  
SHOWER TRIM SET

### Product Information

Applicable product:	
Shower trim with plain cross handles	K-T13134-3A
Valve trim with plain cross handles	K-T13135-3A
Shower trim with grooved cross handles	K-T13134-3B
Valve trim with grooved cross handles	KT-13135-3B
Shower trim with plain lever handles	K-T13134-4A
Valve trim with plain lever handles	K-T13135-4A
Shower trim with grooved lever handles	K-T13134-4B
Valve trim with grooved lever handles	KT-13135-4B
Requires a Rite-Temp <sup>®</sup> K-304-K, K-304-KS, or HiFlow Rite-Temp K-306-KS pressure-balancing valve.	

Required Accessories:	
Rite-Temp <sup>®</sup> valve <b>OR</b>	K-304-*
HiFlow Rite-Temp valve with stops	K-2971-KS
* For a complete listing of all the Rite-Temp valves, refer to the K-304-* Specification Sheet or Roughing-In Sheet.	

Optional Accessories:	
Deep rough-in kit	73418

HiFlow Rite-Temp <sup>®</sup> thin wall installation kit	88526
----------------------------------------------------------	-------

### Installation Notes

Install this product according to the installation guide.

**NOTICE: Risk of product damage.** Long screws, for installing trim, can damage the K-2971-KS valve. Consult the trim installation guide to verify if the thin wall installation kit (88526) is needed.

Avoid cross-flow conditions. Do not install shut-off device on either valve outlet.

Cap shower outlet if deck-mount spout, diverter, or handshower is connected to spout outlet.

Install straight pipe or tube drop of 7" (178 mm) to 18" (457 mm) with single elbow between valve and wall-mount spout.

