



**IMPORTANT
TURN OFF POWER AT MAIN FUSE OR
CIRCUIT BREAKER BOX BEFORE
STARTING INSTALLATION**

Carefully unpack and identify all parts before assembly. Bulbs are not included.

1. Install center body by screwing into center column.
2. Screw threaded pipe into bottom of socket assembly. Note correct position of threaded pipe at illustration.
3. Install arms onto center body by fastening with ball cap nuts.

NOTE: Extra ball cap nuts can be found in a plastic pouch attached inside of box.

4. Follow enclosed **“Chain Suspended Fixture Installation Instructions”** for electrical and fixture installation onto ceiling outlet box.
5. Install bulbs (not included). See relamping label located at socket area for type and maximum allowed wattage.
6. Slip glass shade through threaded pipe until it rests onto bottom section of arms. Lock them into position by fastening with washer and hex nut. Do not over tighten.
7. Slip cap and fasten finial onto threaded pipe.