## STYLE NO: 21829

## Parts and Hardware List

| r unto una m |                     |      |
|--------------|---------------------|------|
| A.           | Chandelier Assembly | 1PC  |
| B.           | Cover Assembly      | 1PC  |
| C.           | Glass               | 1PC  |
| D.           | Cross Bar           | 1PC  |
| E.           | Outlet box Screws   | 2PCS |
| F.           | Pre-Threaded Pipe   | 1PC  |
| G.           | Hex Nut             | 1PC  |
| H.           | Pre-Threaded Ring   | 1PC  |
| I.           | Collar loop         | 1PC  |
| J.           | Canopy              | 1PC  |
| K.           | Wire Nut            | 2PCS |
| L.           | Chain               | 1PC  |
| M.           | Loop                | 1PC  |
| N.           | Quick Link          | 2PCS |
| О.           | Hex Nut             | 1PC  |

Please make sure that you have all the parts indicated beforeyou begin assembly of this item.

Please read Wiring Instuctionsbefore vou begin assembling and installing your Chandelier

WARINIG: BEFORE INSTALLING Make sure electricity supply is shut off to avoid a possible electric shock

## **Assembly Instructions**

- 1. Carefully remove the parts and hardware from the carton.
- 2. Attach the loop (M) to the Chandelier Assembly and secure by turning a clockwise direction
- 3 Fasten the Cross Bar(D)to the outlet box using the Outlet box Screws.
- 4. Insert the shorter end of the Pre-Threaded Pipe(F)into the pre-drilled
- hole in the Cross Bar(D) and secure with the Hex Nut(G).(See Illustration).
- 5. Attach the Collar loop (D)to the exposed end of the Pre-Threaded Pipe(F)
- and secure by turning in a clockwise direction.

  6. Slip the Pre-Threaded Ring (H) First and then the Canopy (J) over the other end of the Chain (L)
- 7.Attach the Quick Links(M) to two bitter end go the Chain(L)
  8. Attach the Quick Link on one end of the Chain(L)to Collar loop (I).
- 9. Attach the other Quick Link on other Chain(L)to the loop on the top of Chandelier Assembly (A).
- 10. Lace the wire through every link of the chain ,through the collar loop and up through the Pre-Threaded Pipe(See Illustration).
- 11. Place the white ,ribbed or tinted wire evenly against the white wirefrom the outlet box and place the black, smooth or un-tinted wire evenly against the black wire from the outlet box .(Connecting the Wire-See Figure2).
- 12. Install the ground wire in the Cross Bar with the green screw supplied.
- 13. After the wires are connected ,tuck them carefully inside the outlet box . Place Canopy(J)over the outlet box and secure with Pre-Threaded Ring(H).
- 14. Attach steel tube to the cover, glass , washer to steel tube then secure
- with Cover Assembly.
- 15. Install 60 Watt, Type A bulbs (sold separately) into the sockets of

CLEANING: This item has a lacquered and baked finish. When cleaning only use a soft, dry cloth. Do not use liquid cleansers or abrasives as they may damage the finish.

