

6" & 8" Back To Back Glass Door Pull Mounting Instructions

*Suit For:

G420-6 G715-6 G718-6 G855-6
G420-8 G715-8 G718-8 G855-8

*Refer to the template on this page for hole locations (A and B).

*Drill holes in door 5/16" (8.0mm) not to exceed 3/8" (9.5mm) diameter at 6" or 8" on center.

*Glass Door Thickness 1/4" (6.0mm) ~ 1/2" (13.0mm).

