

Installation Instructions

SILHOUETTE™ KITCHEN SINKS

MODELS 7145, 7163, 7172, 7179, 7183, 7185, 7196

AMERICAST[®] BRAND SELF RIMMING



Certified to comply with ANSI A112.19.4.M U.S. Patent No. 4,664,982 Other patents pending. CAN/C.S.A. B-45 Observe local plumbing and building codes.

Thank you for selecting American-Standard...the benchmark of fine quality for over 100 years. To ensure that your installation proceeds smoothly--please read these instructions carefully before you begin.

790715-100 Rev. T

BEFORE YOU BEGIN...

Unpack new sink and inspect carefully for damage. Replace the sink in its original packing carton to protect it until you are ready to begin installation.

Recommended Tools & Materials

Silicone Sealant Putty Knife Pipe Wrench Channel Locks Phillips Screwdriver Regular Screwdriver Adjustable Wrench Drill Basin Wrench Saber Saw Tubing Cutter Tape Measure Hacksaw Mineral Spirits Refer to American Standard roughing-in information for specific dimensions for each model.

CUTOUT DIMENSIONS FOR SINKS:

Below are the dimensions needed to determine the cutout size for each sink. Select the correct diagram for your sink and refer to the instructions below.

Locate and mark center lines of sink on countertop.

Provide proper clearance under the countertop for the faucet supply lines and the structural parts of the cabinet.

By using the diagrams below and measuring your sink, draw the outline of the sink onto the countertop. This is not the cutting outline.

Refer to the diagram for your sink and draw a line 5/8" (16mm) in from the sink outline. Cut on this line.



