

# ARTERIALS

## ASSEMBLY INSTRUCTIONS



### ITEM NO: 84310

Description: Analise Chandelier

These instructions are provided for your safety. It is very important that they are read carefully and completely before beginning installation of this chandelier. **We strongly suggest that all hard wired fixtures be installed by a professional electrician. Suitable for dry locations only.**

#### **Parts Included:**

1. Main Body
2. Mounting Plate
3. Canopy
4. Pipes – (1) 6" & (2) 12"
5. Loop
6. Acrylic Diffuser

#### **Hardware Enclosed:**

1. (2) Mounting screws (a)
2. (2) Plastic wire connectors (b)
3. (1) Green ground screw (c)

#### **To Install You Will Need:**

1. 2 people recommended
2. Phillips Screwdriver
3. Electrical tape
4. Wire cutters

#### **To Assemble:**

1. Place main body of chandelier on soft surface for assembly.
2. Included are (1) 6" pipe and (2) 12" pipes. Determine which of these you will need to reach your desired length. At least (1) 6" pipe must be used. Pass the attached electric cable through the desired amount of pipes, keeping the threaded part of the pipes toward the ceiling.
3. Screw each pipe to each other starting with the one closest to the Main Body and moving upwards to the canopy.
4. Pass electric cable through canopy and tighten the last pipe to the collar fixed on the canopy.
5. **SHUT OFF MAIN ELECTRICAL SUPPLY FROM THE MAIN FUSE BOX/CIRCUIT BREAKER.**
6. Gently pull wiring down from ceiling junction box and allow to hang.
7. Remove mounting plate from the canopy by unscrewing the collar.
8. Carefully inspect the chandelier's fixture wires. The neutral fixture wire has very fine ridges molded into its plastic covering. The hot fixture wire has a smooth covering. The bare copper wire is the ground wire.
9. Wrap ground wire of lamp assembly and ground wire of junction box together and fasten together with a wire nut and wrap the connection with electrical tape.
10. Attach the neutral fixture wire from the pendant to the neutral junction box wire (usually white). Fasten each together with a wire nut and wrap the connection with electrical tape.
11. Attach the hot fixture wire from the pendant to the hot junction box wire (usually black). Fasten each together with a wire nut and wrap the connection with electrical tape.  
**DO NOT REVERSE THE HOT AND NEUTRAL CONNECTIONS OR SAFETY WILL BE COMPROMISED.**
12. Gently tuck the wire connections neatly into the ceiling junction box.
13. Align holes in mounting plate with holes in junction box and attach with two mounting bolts. Secure bolts with a Phillips head screwdriver.
14. Push canopy up over the mounting plate until it is flush with the ceiling.
15. Push collar through hole in canopy and thread onto nipple on the mounting plate. Secure by turning collar clockwise until canopy is flush with the ceiling.
16. Insert (8) TYPE B 25 W bulbs (not included) into the socket. **DO NOT EXCEED SPECIFIED WATTAGE.**
17. Restore power to junction box and test fixture.

#### **CARE INSTRUCTIONS**

Wipe with a soft, dry cloth. To protect finish, avoid the use of chemicals and household cleaners.