

# ITEM#79680

## Yasmin Antique Brass/Antique Black Iron Floor Lamp

### Part

|                 |      |                   |       |
|-----------------|------|-------------------|-------|
| BASE(A)         | 1 PC | SOCKET RING(E)(G) | 2 PCS |
| COLUMN(B)       | 1 PC | Brass Washer(a)   | 1 PC  |
| FINIAL(C)       | 1 PC | Locker Washer(b)  | 1PC   |
| TOP SHADE(D)    | 1 PC | Hexagon Nut(c)    | 1PC   |
| BOTTOM SHADE(F) | 1 PC | Wrench(d)         | 1PC   |

### ASSEMBLY INSTRUCTIONS

1. REMOVE ALL LAMP PARTS FROM THE PACKAGE CAREFULLY .
2. PULL EXCESS WIRE THROUGH THE BASE BEFORE ASSEMBLING THE LAMP.
- 3.PASS THE TIP OF COLUMN (B)THROUGH Brass Washer(a), BASE (A),AND Locker Washer(b) THEN TIGHT THE BASE BY SCREWING Hexagon nut(c )with Wrench(d) TILL TIGHT.
4. SCREW THE FINIAL(C ) ON THE TOP OF COLUMN(B)
5. UNSCREW THE SOCKET RING(E)FROM THE SOCKET THEN ATTACH THE TOP SHADE(D) ONTO THE SOCKET,TIGHTEN SOCKET RING (E) CLOCKWISE TO SECURE THE SHADE.
6. REPEAT THE ABOVE OPERATION ON THE BOTTOM SHADE(F).

### IMPORTANT SAFETY INSTRUCTIONS

This portable lamp has a polarized plug (one blade is wider than the other) as a feature to reduce the risk of electric shock. This plug will fit in a polarized outlet only one way. If the plug does not fit fully in the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Never use with an extension cord unless plug can be fully inserted. Do not alter the plug.

