

# # DK42043 Chainmail 3L Brass/Glass Pendant

## IMPORTANT SAFETY INSTRUCTIONS:

These instructions are provided for your safety. Please read all instructions carefully before assembling. We strongly recommend that all hard wired fixtures be installed by a professional electrician. THIS PRODUCT MUST BE INSTALLED IN ACCORDANCE WITH THE APPLICABLE INSTALLATION CODE BY A PERSON FAMILIAR WITH THE CONSTRUCTION AND OPERATION OF THE PRODUCT AND HAZARDS INVOLVED.

## PRE-ASSEMBLY:

Gently hook the suspended chain from the bottom with the METAL RING marked as "hanging chain" one by one & secure it by tightening the screw, apply same procedure to all remaining suspended chains. Now hold the rods coming out from socket & hook it with the METAL RING marked as "socket hook" repeat the same for all remaining rods.

## ELECTRIFICATION INSTRUCTIONS:

1. SHUT OFF MAIN ELECTRICAL SUPPLY FROM THE MAIN FUSE BOX/CIRCUIT BREAKER.
2. Gently pull wiring down from ceiling junction box and allow to hang.
3. Remove the Mounting Plate (A) from the Canopy (B) by turning the Collar Loop (J) head in a counter clockwise direction.
4. Carefully inspect the chandelier's fixture wires. The neutral fixture wire has very fine ridges molded into its plastic covering. The hot fixture wire has a smooth covering. The bare copper wire is the ground wire.
5. Attach the ground wire from the fixture to the ground junction box wire from the outlet (usually green or bare wire). Fasten each together with a Plastic Wire Connector (H) and wrap the connection with electrical tape. If your outlet box does not have a ground wire, insert the Ground Screw (I) into the Mounting Plate (A) facing down, and wrap the fixture's bare ground wire around the Ground Screw (I). IT IS IMPERATIVE THAT THE OUTLET BOX IN YOUR HOME BE PROPERLY GROUNDED.
6. Connect the neutral fixture wire has clear color with tracer (raised longitudinal ridges) to the neutral junction box wire (usually white). Fasten each together with a Plastic Wire Connector (H) and wrap the connection with with electrical tape. Be sure no strands are exposed.
7. Connect the hot fixture wire has clear color with smooth surface to the hot junction box wire (usually black). Fasten each together with a Plastic Wire Connector (H) and wrap the connection with electrical tape. Be sure no wire strands are exposed. DO NOT REVERSE THE HOT AND NEUTRAL CONNECTIONS OR SAFETY WILL BE COMPROMISED.

## TO CONNECT WIRES TOGETHER:





- a) Use a wire stripper and wire cutters to strip the plastic wire casing from each wire, so that approximately 1 inch of wire is exposed.
- b) Align the wire from the fixture and the wire from the outlet next to each other.
- c) Twist the Plastic Wire Connector (H) onto the exposed metal wire pair to hold the connection.
- d) Inspect the connection for protruding or exposed metal wire strands. Retighten the nut or cut any loose strands.
- e) Use a piece of electrical tape to wrap around the wire nut and the connected wires to further protect the connection.

8. Gently tuck the wire connections neatly into the ceiling junction box
9. Attach the Mounting Plate (A) with nipple to the ceiling outlet box using the enclosed Mounting Screws (G) and tighten screws with a screwdriver.
10. Push Canopy (B) up over the Mounting Plate (A) until it is flush with the ceiling
11. Push Collar Loop (J) through hole in Canopy (B) and thread onto nipple in Mounting Plate (A) by turning in a clockwise direction until the Canopy (B) is flush with the ceiling.
12. Insert 3 Type B 25 Watt bulbs (not included) into the candelabra sockets. DO NOT EXCEED SPECIFIED WATTAGE.
13. Restore power to the junction box and test fixture.
14. Assembly is complete.

## CARE INSTRUCTIONS:

Wipe clean using a soft, dry cloth or static duster.  
Always avoid the use of harsh chemicals and abrasives to clean fixture as they may damage the finish.

# # DK42043 Chainmail 3L Brass/Glass Pendant

	<b>H</b>
	<b>I</b>
	<b>G</b>
	<b>J</b>

