

ARTERIOR'S HOME  
Laura Kirar Collection  
CHANDELIER INSTALLATION INSTRUCTIONS  
Caviar Medium Pendant

These instructions are provided for your safety. It is very important that they are read carefully and completely before beginning installation of this chandelier. **We strongly suggest that all hard wired fixtures be installed by a professional electrician.**

**Parts Included:**

1. Mounting Plate (A)
2. Canopy (B)
3. Collar Loop (C)
4. Rods (D)(E)(F).
5. Socket Assembly (G)
6. Glass Shade (H)
7. Metal Cone (I)

**Hardware Enclosed:**

1. (2) Mounting screws (a)
2. (2) Plastic wire connectors (b)
3. (1) Green ground screw (c)
4. (5) Little screws(d)
5. (1)Wrench(e)
6. (1)Bulb Driver(f)

**To Install You Will Need:**

1. 2 people recommended
2. Phillips Screwdriver
3. Electrical tapeWire cutters

**To Assemble:**

1. SHUT OFF THE MAIN ELECTRICAL SUPPLY FROM THE MAIN FUSE BOX/CIRCUIT BREAKER.
2. Carefully unpack all fixture parts and hardware and lay them out on a clear workspace.
3. Gently pull wiring down from ceiling junction box and allow it to hang.
4. Screw the Rod (E) to the Rod (E), and tighten the little screw (d) in the side desire hole by wrench(e).  
Repeat the same operation to connect Longer Rod (F) and Socket Assembly (G).
5. Remove the mounting plate (A) from the canopy (B) by turning collar loop Collar (C) in a counter clockwise direction.
6. Carefully inspect the pendant's fixture wires. The NEUTRAL FIXTURE WIRE has very fine ridges molded into its plastic covering. The HOT FIXTURE WIRE has a smooth covering. The bare silver wire is the GROUND WIRE.
7. Attach the GROUND WIRE from the fixture to the GROUND JUNCTION BOX WIRE from the outlet (usually green or bare wire). Fasten each together with a plastic wire connector (b) and wrap the connection with electrical tape. If your outlet box DOES NOT have a GROUND WIRE, insert the green ground screw (c) into the mounting plate (A) facing DOWN, and wrap the fixture's bare ground wire around the ground screw. **IT IS IMPERATIVE THAT THE OUTLET BOX IN YOUR HOME BE PROPERLY GROUNDED.**
8. Connect the NEUTRAL FIXTURE WIRE to the NEUTRAL JUNCTION BOX WIRE (usually white). Fasten each together with a wire connector (b) and wrap the connection with electrical tape. Be sure no strands are exposed.
9. Connect the HOT FIXTURE WIRE to the HOT JUNCTION BOX WIRE (usually black). Fasten each together with a plastic wire connector (b) and wrap the connection with electrical tape. Be sure no wire strands are exposed. **DO NOT REVERSE THE HOT AND NEUTRAL CONNECTIONS OR SAFETY WILL BE COMPROMISED.**
10. Gently tuck the wire connections neatly into the ceiling junction box.
11. Attach the mounting plate (A) with nipple to the ceiling outlet box using the enclosed mounting screws (a) and tighten screws with a screwdriver.
12. Push Collar Loop(d) in canopy (B) and thread onto nipple in mounting plate (A) by turning in a clockwise direction until the canopy is flush with the ceiling
13. Screw Rod (D) to Canopy (C), tighten it with the little screw in the desire side hole by wrench.
14. Attached Glass Shade (H) to the Socket Assembly (G),push Metal Cone(I) through Glass Shade, Then screw it onto the Socket Assembly(G) till tight.
15. Insert One TYPE B 40W bulb (not included) into the socket with Bulb Driver (f). **DO NOT EXCEED SPECIFIED WATTAGE.**

16. Restore power to junction box and test fixture.
17. Assembly is complete.

**Care Instructions:**

- Wipe clean using a soft, dry cloth or static duster.
- Always avoid the use of harsh chemicals and abrasives to clean fixture as they may damage the finish.

