

ASSEMBLY INSTRUCTIONS

ITEM #49267 | Tarbell Semi-Flush

ITEM DESCRIPTION

MATERIAL TYPE: STEEL.ACRYL FINISH:HERITAGE BRASS.MILK TOP COAT/SEALANT:
 SOCKET TYPE: E12 CERAMIC SOCKET QTY:3
 BULB TYPE: TYPE B BULB WATTAGE: 40W or/CFL 10W or/LED 9W
 ITEM NET WEIGHT: TOP COAT/SEALANT:

UL COMPLAINT
 INSTALLATION ENVIRONMENT:SUITABLE FOR DAMP LOCATIONS






NOTE:
 *YOUR PRODUCT(S) MAY BE PACKED IN MORE THAN ONE CARTON
 *THIS ITEM MAY REQUIRE PERIODIC TIGHTENING


PARTS

	MOUNTING PLATE	1 PC
B	CANOPY	1 PC
C	COLLAR LOOP	1 PC
D	ROD	1 PC
E	SOCKET ASSEMBLY	1 PC
F	METAL SHADE	1 PC
G	PIPE	1 PC
H	DIFFUSEER	1 PC
I	WASHER	1 PC
J	FINIAL	1 PC

INCLUDED ASSEMBLY HARDWARE

K Plastic wire connectors 	L mounting screws 	M allen wrench 
--	--	---

PRODUCT ASSEMBLY



ASSEMBLY INSTRUCTIONS

- 1.REMOVE ALL PACKING CONTENTS FROM THE CARTON(S)CAREFULLY
- 2.REMOVE ALL PARTS FROM THE PACKAGE(S) CAREFULLY
- 3.PLEASE BE SURE YOU HAVE ALL PARTS INDICATED BEFORE YOU BEGIN ASSEMBLY
- 4.SHUT OFF THE MAIN ELECTRICAL SUPPLY FROM THE MAIN FUSE BOX/CIRCUIT BREAKER
- 5.REMOVE THE MOUNTING PLATE(A)FROM THE CANOPY(B)BY TURNING COLLAR LOOP(C) IN A COUNTER CLOCKWISE DIRECTION.
- 6.SCREW THE ROD(D) TO THE TOP OF METAL SAHDE (F) ,AND TIGHTEN THE HEXANGULAR SCREW IN THE SIDE DESIRE HOLE BY ALLEN WRENCH(M) .
- 7.THREAD THE PIPE(G) TO THE BOTTOM OF SOCKET ASSEMBLY (E) TILL TIGHT .
- 8.LIFT THE ACRYLIC DIFFUSER(H) IN THE BOTTOM RIM OF METAL SHADE PROPERLY, AND COVER THE WASHER(I) ,AND THEN TIGHT THE FINIAL(J) TO SECURE IT.
- 9.CAREFULLY INSPECT THE PENDANT'S FIXTURE WIRES. THE NEUTRAL FIXTURE WIRE HAS VERY FINE RIDEGS MOLDED INTO ITS PLASTIC COVERING. THE HOT FIXTURE WIRE HAS A SMOOTH COVERING.THE BARE SILVER WIRE IS THE GROUNDED WIRE.
- 10.ATTACH THE GROUND WIRE FROM THE FIXTURE TO THE GROUND JUNCTION BOX WIRE FROM THE OUTLET (USUALLY GREEN) OR BARE WIRE). FASTEN EACH TOGETHER WITH A PLASTIC WIRE CONNECTOR (K) AND WRAP THE CONNECTION WITH ELECTRICAL TAPE. IF YOUR OUTLET BOX DOES NOT HAVE A GROUND WIRE, INSERT THE GREEN GROUND SCREW INTO THE MOUNTING PLATE (A) FACING DOWN, AND WRAP THE FIXTURE'S BARE GROUND WIRE AROUND THE GROUND SCREW. IT IS IMPERATIVE THAT THE OUTLET BOX IN YOUR HOME BE PROPERLY GROUNDED.
11. CONNECT THE NEUTRAL FIXTURE WIRE TO THE NEUTRAL JUNCTION BOX WIRE (USUALLY WHITE). FASTEN EACH TOGETHER WITH A WIRE CONNECTOR (K) AND WRAP THE CONNECTION WITH ELECTRICAL TAPE. BE SURE NO STRANDS ARE EXPOSED.
- 12.CONNECT THE HOT FIXTURE WIRE TO THE HOT JUNCTION BOX WIRE (USUALLY BLACK). FASTEN EACH TOGETHER WITH A PLASTIC WIRE CONNECTOR (K) AND WRAP THE CONNECTION WITH ELECTRICAL TAPE. BE SURE NO WIRE STRANDS ARE EXPOSED. DO NOT REVERSE THE HOT AND NEUTRAL CONNECTIONS OR SAFETY WILL BE COMPROMISED.
13. GENTLY TUCK THE WIRE CONNECTIONS NEATLY INTO THE CEILING JUNCTION BOX.
- 14.ATTACH THE MOUNTING PLATE (A) WITH NIPPLE TO THE CEILING OUTLET BOX USING THE ENCLOSED MOUNTING SCREWS (L) AND TIGHTEN SCREWS WITH A SCREWDRIVER.
15. PUSH COLLAR LOOP IN CANOPY (B) AND THREAD ONTO NIPPLE IN MOUNTING PLATE (A) BY TURNING IN A CLOCKWISE
- 16.SCREW ROD (D) TO CANOPY (B), USING HEXANGULAR SCREW AND ALLEN WRENCH(M)
 BE SURE ALL THE HEXANGULAR SCREWS ARE TIGHT ENOUGH.
- 17.INSERT 3 TYPE B 40W BULBS(OR SUITABLE /CFL 10W OR/LED 9W BULBS ,NOT INCLUDED) IN THE SOCKETS.
DO NOT EXCEED SPECIFIED WATTAGE .

CARE & MAINTENANCE

FOR CUSTOMER SERVICE QUESTION CALL 1-800-338-2150 **DISCLAIMERS**

ARTERIOS HOME:972.488.9800

ARTERIOS CONTRACT:972.488.9800 EXT.:321

WE RECOMMEND THE INSTALLATION OF THIS ELECTRICAL LIGHT FIXTURE TO BE DONE BY A LICENSED ELECTRICIAN.

ARTERIOS