ASSEMBLY INSTRUCTIONS

ITEM DESCRIPTION

MATERIAL TYPE: STEEL.LINEN-COTTON FINISH :CHATTERED ANTIQUE BRASS.PURE WHITE SOCKET TYPE: E12 BAKELITE SOCKET QTY:6 TOP COAT/SEALANT:

BULB TYPE: TYPE G BULB WATTAGE: 60W or/CFL 16W or/LED 13W

ITEM NET WEIGHT: TOP COAT/SEALANT:

UL COMPLAINT

INSTALLATION ENVIRONMENT: SUITABLE FOR DAMP LOCATIONS

INOTE:

*YOUR PRODUCT(S) MAY BE PACKED IN MORE THAN ONE CARTON

*THIS ITEM MAY REQUIRE PERIODIC TIGHTENING



PARTS

_		
A	MOUNTING PLATE	1 PC
В	CANOPY	1 PC
С	COLLAR LOOP	1 PC
D	RODS	4 PCS
Ε	MAIN BODY	1 PC
F	METAL LOOP	6 PCS
G	SHADE	6 PCS
Н	SOCKET RING	6 PCS
I	DIFFUSER	6 PCS

INCLUDED ASSEMBLY HARDWARE



ASSEMBLY INSTRUCTIONS

- 1.REMOVE ALL PACKING CONTENTS FROM THE CARTON(S)CAREFULLY.
- 2.REMOVE ALL PARTS FROM THE PACKAGE(S) CAREFULLY.
- 3.PLEASE BE SURE YOU HAVE ALL PARTS INDICATED BEFORE YOU BEGIN ASSEMBLY.
- 4.SHUT OFF THE MAIN ELECTRICAL SUPPLY FROM THE MAIN FUSE BOX/CIRCUIT BREAKER.
- 5.REMOVE THE MOUNTING PLATE(A)FROM THE CANOPY(B)BY TURNING COLLAR LOOP(C)

IN A COUNTER CLOCKWISE DIRECTION.

- 6.SCREW THE PIPE(D3) ONTO THE MAIN BODY (E),AND TIGHTEN THE HEXANGULAR SCREW IN THE SIDE DESIRE HOLE BY ALLEN WRENCH(L).
- 7.THREAD THE ROD(D3) TO THE PIPE(E), REPEAT THE SAME OPERATION ON THE ROD (D1)AND (D2)
- IF THE CEILING IS HIGH ENOUGH, PLS ASSEMBLE THE ROD(D4)IF NEED.
- 8.UNSCREW THE SOCKET RING(H)OFF THE SOCKET. ATTACH THE SHADE(G) TO THE SOCKET AND SECURE WITH SOCKET RING TILL TIGHT.
 PLS BE SURE THE METAL LOOP(F) IS PROPERLY COVERED THE TOP SHADE.
- 9.INSERT TYPE G 60W BULB (OR SUITABLE CFL 16W/LED 13W BULBS ,NOT INCLUDED) IN THE SOCKET.**DO NOT EXCEED SPECIFIED WATTAGE.**
- 10.ATTACH THE DIFFUSER(I) TO THE SHADE, AND AS DRAWING SHOWN,INSERT IT INTO BOTTOM SHADE CAREFULLY TILL SECURE.

REPEAT THE ABOVE STEP(8),(9)AND(10) ON THE REMAINNING 5PCS SHADE.

- 11.CAREFULLY INSPECT THE PENDANT'S FIXTURE WIRES. THE NEUTRAL FIXTURE WIRE HAS VERY FINE RIDEGS MOLDED
 INTO ITS PLASTIC COVERING. THE HOT FIXTURE WIRE HAS A SMOOTH COVERING.THE BARE SILVER WIRE IS THE GROUNDED WIRE.
- 12.ATTACH THE GROUND WIRE FROM THE FIXTURE TO THE GROUND JUNCTION BOX WIRE FROM THE OUTLET (USUALLY GREEN)
- OR BARE WIRE). FASTEN EACH TOGETHER WITH A PLASTIC WIRE CONNECTOR (J) AND WRAP THE CONNECTION WITH
- ELECTRICAL TAPE. IF YOUR OUTLET BOX DOES NOT HAVE A GROUND WIRE, INSERT THE GREEN GROUND SCREW INTO THE MOUNTING PLATE (A) FACING DOWN, AND WRAP THE FIXTURE'S BARE GROUND WIRE AROUND THE GROUND SCREW.
- IT IS IMPERATIVE THAT THE OUTLET BOX IN YOUR HOME BE PROPERLY GROUNDED.
- 13.CONNECT THE NEUTRAL FIXTURE WIRE TO THE NEUTRAL JUNCTION BOX WIRE (USUALLY WHITE). FASTEN EACH TOGETHER
 WITH A WIRE CONNECTOR (J) AND WRAP THE CONNECTION WITH ELECTRICAL TAPE. BE SURE NO STRANDS ARE EXPOSED.
- 14.CONNECT THE HOT FIXTURE WIRE TO THE HOT JUNCTION BOX WIRE (USUALLY BLACK). FASTEN EACH TOGETHER
 WITH A PLASTIC WIRE CONNECTOR (J) AND WRAP THE CONNECTION WITH ELECTRICAL TAPE. BE SURE NO WIRE STRANDS
 ARE EXPOSED. DO NOT REVERSE THE HOT AND NEUTRAL CONNECTIONS OR SAFETY WILL BE COMPROMISED.
- 15. GENTLY TRUCK THE WIRE CONNECTIONS NEATLY INTO THE CEILING JUNCTION BOX.
- 16.ATTACH THE MOUNTING PLATE (A) WITH NIPPLE TO THE CEILING OUTLET BOX USING THE ENCLOSED MOUNTING SCREWS (K) AND TIGHTEN SCREWS WITH A SCREWDRIVER.
- 17. PUSH COLLAR LOOP IN CANOPY (B) AND THREAD ONTO NIPPLE IN MOUNTING PLATE (A) BY TURNING IN A CLOCKWISE
- 18.SCREW ROD (D1) TO THE CANOPY (B)BY USING HEXANGULAR SCREW AND ALLEN WRENCH(L)

BE SURE ALL THE HEXANGULAR SCREWS ARE TIGHT ENOUGH.

CARE & MAINTENANCE

FOR CUSTOMER SERVICE QUESTION CALL 1-800-338-2150 DISCLAIMERS

ARTERIORS HOME:972.488.9800

WE RECOMMEND THE INSTALLATION OF THIS ELECTICAL LIGHT FIXTURE TO BE DONE BY A LICENSED ELECTRICIAN.

ARTERIORS CONTRACT:972.488.9800 EXT.321

