# ASSEMBLY INSTRUCTIONS

#### ITEM DESCRIPTION

MATERIAL TYPE: STEEL.GLASS FINISH:ANTIQUE BRASS.OPAL WHITE SOCKET TYPE: E12 CERAMIC SOCKET QTY:12 TOP COAT/SEALANT:

BULB TYPE: TYPE G BULB WATTAGE: 25W/CFL 7W/LED 5W

ITEM NET WEIGHT: VOLTAGE:110V-120V

**UL COMPLAINT** 

INSTALLATION ENVIRONMENT: SUITABLE FOR DAMP LOCATIONS

#### INOTE

\*YOUR PRODUCT(S) MAY BE PACKED IN MORE THAN ONE CARTON
\*THIS ITEM MAY REQUIRE PERIODIC TIGHTENING

# ITEM #89631 | CHANDELIER



#### PARTS

Α	MOUNTING PLATE	1 PC
В	CANOPY	1 PC
C	COLLAR LOOP	1 PC
D	RODS	3 PCS
Ε	WIRING SPHERE	1 PC
F	SOCKET PIPE	8 pcs
G	SOCKET ASSEMBLY	12 pcs
Н	METAL RING	12 pcs
ı	GLASS SPHERE	12 pcs
		•

Not include 6pcs fixed

### **INCLUDED ASSEMBLY HARDWARE**



## ASSEMBLY INSTRUCTIONS

1.REMOVE ALL PACKING CONTENTS FROM THE CARTON(S)CAREFULLY

2.REMOVE ALL PARTS FROM THE PACKAGE(S) CAREFULLY

3.SHUT OFF THE MAIN ELECTRICAL SUPPLY FROM THE MAIN FUSE BOX/CIRCUIT BREAKER

4.SCREW THE ROD(D3) TO THE WIRING SPHERE (E),AND TIGHTEN THE HEXANGULAR SCREW IN THE

SIDE HOLE WITH ALLEN WRENCH(L) .REPEAT THE SAME OPERATION ON THE ROD (D1)AND (D2).

5.SCREW THE SOCKET PIPE(F) GENTLY TO ONTO THE WIRING SPHERE TILL TIGHT.

REPEAT THE SAME OPERATON ON THE REMAINING 5PCS SOCKET PIPES. (6PCS SOCKET PIPES ALREADY FIXED).

6.AS FIG 1,UNSCREW THE METAL RING(H) OFF THE SOCKET ASSEMBLY(G), INSERT TYPE G 25W BULB( OR SUITABLE /CFL 7W OR/LED 5W BULB, NOT INCLUDED) IN THE SOCKET. DO NOT EXCEED SPECIFIED WATTAGE .AND ATTACH THE GLASS SPHERE(I) TO THE SOCKET ASSEMBLY (G) PROPERLY,

THEN SCREW THE METAL RING(H)TO SECURE THE GLASS SPHERE TILL TIGHT.

REPEAT THE ABOVE OPERATONS ON THE REMAINING 11PCS GLASS SPHERE.

7.REMOVE THE MOUNTING PLATE(A)FROM THE CANOPY(B)BY TURNING COLLAR LOOP(C) IN A COUNTER CLOCKWISE DIRECTION.

B.CAREFULLY INSPECT THE PENDANT'S FIXTURE WIRES. THE NEUTRAL FIXTURE WIRE HAS VERY FINE RIDEGS MOLDED

INTO ITS PLASTIC COVERING. THE HOT FIXTURE WIRE HAS A SMOOTH COVERING. THE BARE SILVER WIRE IS THE GROUNDED WIRE.

9. ATTACH THE GROUND WIRE FROM THE FIXTURE TO THE GROUND JUNCTION BOX WIRE FROM THE OUTLET (USUALLY GREEN)

OR BARE WIRE). FASTEN EACH TOGETHER WITH A PLASTIC WIRE CONNECTOR (J) AND WRAP THE CONNECTION WITH

ELECTRICAL TAPE. IF YOUR OUTLET BOX DOES NOT HAVE A GROUND WIRE, INSERT THE GREEN GROUND SCREW

INTO THE MOUNTING PLATE (A) FACING DOWN, AND WRAP THE FIXTURE'S BARE GROUND WIRE AROUND THE GROUND SCREW.

IT IS IMPERATIVE THAT THE OUTLET BOX IN YOUR HOME BE PROPERLY GROUNDED.

10. CONNECT THE NEUTRAL FIXTURE WIRE TO THE NEUTRAL JUNCTION BOX WIRE (USUALLY WHITE). FASTEN EACH TOGETHER WITH A WIRE CONNECTOR (J) AND WRAP THE.CONNECTION WITH ELECTRICAL TAPE. BE SURE NO STRANDS ARE EXPOSED.

I1.CONNECT THE HOT FIXTURE WIRE TO THE HOT JUNCTION BOX WIRE (USUALLY BLACK). FASTEN EACH TOGETHER
WITH A PLASTIC WIRE CONNECTOR (J) AND WRAP THE CONNECTION WITH ELECTRICAL TAPE. BE SURE NO WIRE STRANDS

WITH A PLASTIC WIRE CONNECTOR (J) AND WRAP THE CONNECTION WITH ELECTRICAL TAPE. BE SURE NO WIRE STRAN ARE EXPOSED. DO NOT REVERSE THE HOT AND NEUTRAL CONNECTIONS OR SAFETY WILL BE COMPROMISED.

12. GENTLY TUCK THE WIRE CONNECTIONS NEATLY INTO THE CEILING JUNCTION BOX.

13.ATTACH THE MOUNTING PLATE (A) WITH NIPPLE TO THE CEILING OUTLET BOX USING THE ENCLOSED MOUNTING SCREWS (K) AND TIGHTEN SCREWS WITH A SCREWDRIVER.

14. PUSH COLLAR LOOP IN CANOPY (B) AND THREAD ONTO NIPPLE IN MOUNTING PLATE (A) BY TURNING IN A CLOCKWISE

15.SCREW ROD (D1) TO CANOPY (B), USING HEXANGULAR SCREW AND ALLEN WRENCH(L)

BE SURE ALL THE HEXANGULAR SCREWS ARE TIGHT ENOUGH.

### **CARE & MAINTENANCE**

FOR CUSTOMER SERVICE QUESTION CALL 1-800-338-2150

ARTERIORS CONTRACT:972.488.9800 EXT.321

DISCLAIMERS

ARTERIORS HOME:972.488.9800

WE RECOMMEND THE INSTALLATION OF THIS ELECTICAL LIGHT FIXTURE TO BE DONE BY A LICENSED ELECTRICIAN.

ARTFRIORS

