

ASSEMBLY INSTRUCTIONS

ITEM # DWC16 / SCONCE

ITEM DESCRIPTION

MATERIAL TYPE:IRON + GLASS

FINISH :ANTIQUE BRASS + SLUMP CLEAR SEEDY GLASS

TOP COAT/SEALANT

SOCKET TYPE:LED

SOCKET QTY: 4PCS

BULB TYPE: LED

BULB WATTAGE:7W

VOLTAGE:110V-120V

ITEM NET WEIGHT:

UL COMPLIANT

INSTALLATION ENVIRONMENT:SUITABLE FOR DAMP LOCATIONS



NOTE:


\*YOUR PRODUCT(S) MAY BE PACKED IN MORE THAN ONE CARTON

\*THIS ITEM MAY REQUIRE PERIODIC TIGHTENING

\*MIN 90°C SUPPLY CONDUCTORS

PARTS

|   |                |       |
|---|----------------|-------|
| A | MOUNTING PLATE | 1 PC  |
| B | BACK PLATE     | 1 PC  |
| C | SCREW          | 2 PCS |






PRODUCT ASSEMBLY

INCLUDED ASSEMBLY HARDW

J MOUNTING SCREWS

K PLASTIC WIRE CONNECTORS



ASSEMBLY INSTRUCTIONS

- 1.REMOVE ALL PACKING CONTENTS AND PARTS FROM THE CARTON(S)CAREFULLY.
- 2.PLEASE BE SURE YOU HAVE ALL PARTS INDICATED BEFORE YOU BEGIN ASSEMBLY.
- 3.SHUT OFF THE MAIN ELECTRICAL SUPPLY FROM THE MAIN FUSE BOX/CIRCUIT BREAKER.
- 4.PULL THE ELECTRICAL CORD OF "J BOX"THROUGH THE EXIT HOLE OF THE MOUNTING PLATE(A)
- 5.PLEASE PAY SPECIAL ATTENTION THAT YOU DO NOT NEED TO CONNECT THE WIRE CONNECT DEVICE(M).  
IT IS USED FOR THE WIRE CONNECTION FOR EURO-MARKET.
- 6.ATTACH THE MOUNTING PLATE (A) TO THE OUTLET BOX BY USING THE ENCLOSED MOUNTING SCREW (J), AND TIGHTEN IT WITH A SCREWDRIVER.
- 7.ATTACH THE KEY CHAIN ON THE AIRCRAFT WIRE OF THE BACK PLATE TO THE MOUNTING PLATE(A).
- 8.CAREFULLY INSPECT THE FIXTURE WIRES. THE NEUTRAL FIXTURE WIRE HAS VERY FINE RIDEGS MOLDED INTO ITS PLASTIC COVERING. THE HOT FIXTURE WIRE HAS A SMOOTH COVERING.THE BARE WIRE IS THE GROUNDED WIRE.
9. ATTACH THE GROUND WIRE FROM THE FIXTURE TO THE GROUND JUNCTION BOX WIRE FROM THE OUTLET (USUALLY GREEN OR BARE WIRE). FASTEN EACH TOGETHER WITH A PLASTIC WIRE CONNECTOR (K) AND WRAP THE CONNECTION WITH ELECTRICAL TAPE. IF YOUR OUTLET BOX DOES NOT HAVE A GROUND WIRE, INSERT THE GREEN GROUND SCREW INTO THE MOUNTING PLATE (A) FACING DOWN, AND WRAP THE FIXTURE'S BARE GROUND WIRE AROUND THE GROUND SCREW. **IT IS IMPERATIVE THAT THE OUTLET BOX IN YOUR HOME BE PROPERLY GROUNDED.**
- 10.CONNECT THE NEUTRAL FIXTURE WIRE TO THE NEUTRAL JUNCTION BOX WIRE (USUALLY WHITE). FASTEN EACH TOGETHER WITH A WIRE CONNECTOR (K) AND WRAP THE CONNECTION WITH ELECTRICAL TAPE. BE SURE NO STRANDS ARE EXPOSED.
- 11.CONNECT THE HOT FIXTURE WIRE TO THE HOT JUNCTION BOX WIRE (USUALLY BLACK). FASTEN EACH TOGETHER WITH A PLASTIC WIRE CONNECTOR (K) AND WRAP THE CONNECTION WITH ELECTRICAL TAPE. BE SURE NO WIRE STRANDS ARE EXPOSED.  
**DO NOT REVERSE THE HOT AND NEUTRAL CONNECTIONS OR SAFETY WILL BE COMPROMISED.**
- 12.GENTLY TUCK THE WIRE CONNECTIONS(K) NEATLY INTO THE CEILING JUNCTION BOX.
13. ATTACH THE BACK PLATE (B) ONTO THE MOUNTING PLATE (A) WITH 2PCS SET SCREWS (C), AND TIGHTEN IT WITH A SCREWDRIVER.
- 14.RESTORE POWER TO THE JUNCTION BOX AND TEST FIXTURE.

CARE & MAINTENANCE

DUST WITH A DRY CLOTH.

DISCLAIMERS

FOR CUSTOMER SERVICE QUESTIONS CALL 1.888.488.8866

WE RECOMMEND THE INSTALLATION OF THIS ELECTICAL LIGHT FIXTURE TO BE DONE BY A LICENSED ELECTRICIAN.

ARTERIORS HOME:972.488.9800

ARTERIORS CONTRACT:972.488.9800 EXT.321

ARTERIORS